





0199




| Position ID | Part No. | Replacement | Description |
|--------------------|-----------------|--------------------|-----------------------------|
| 0101 | 00753598 | | Cover |
| 0102 | 00629584 | | Knob-programme |
| 0103 | 00962824 | | Coupling |
| 0104 | 00753596 | | Display |
| 0106 | 00643560 | | Power cord |
| 0107 | 00749020 | | Panel-facia |
| 0110 | 00753599 | | Operating module programmed |
| 0108 | 00753700 | | Power module not programmed |
| 8401 | 00785090 | | Instruction manual |
| 8402 | 00785093 | | Instruction manual |
| 8403 | 00785095 | | Instruction manual |
| 0122 | 00753676 | | Cover |
| 0121 | 00753672 | | Panel-insert |
| 0120 | 00753673 | | Panel-insert |
| 0108 | 00631326 | | Power module programmed |




| Position ID | Part No. | Replacement | Description |
|--------------------|-----------------|--------------------|---------------------|
| 0201 | 00711862 | | Panel side |
| 0202 | 00711862 | | Panel side |
| 0203 | 00687302 | | Front panel |
| 0204 | 00475305 | | Hood |
| 0205 | 00621457 | 00621457 | Sealing |
| 0206 | 00649016 | | Heating element |
| 0207 | 00600157 | | Sensor NTC |
| 0208 | 00617454 | | Limiter-temperature |
| 0209 | 00713057 | | Case-rear part |
| 0212 | 00749071 | | Duct |
| 0213 | 00445049 | | Duct |
| 0214 | 00623797 | | Latch |
| 0215 | 00613752 | | Seal |
| 0216 | 00613753 | | Sensor-NTC |
| 0217 | 00749091 | | Electrode |
| 0219 | 00713051 | | Bearing shield |
| 0220 | 00623850 | | Switch-door |
| 0223 | 00753637 | | Filter-fluff |
| 0224 | 00624178 | | Holder |
| 0226 | 00600811 | | Holder |
| 0227 | 00623796 | | Cover |
| 0229 | 00609166 | | Holder |
| 0230 | 00687305 | | Worktop |
| 0231 | 00613598 | | Wheel |
| 0234 | 00605995 | | Plug |
| 0235 | 00605994 | | Terminal |
| 0236 | 00605996 | | Cable harness |


| | | | |
|------|----------|--|--------------------|
| 0237 | 00707070 | | Front rail |
| 0238 | 00649053 | | Ventilation duct |
| 8401 | 00785090 | | Instruction manual |
| 8402 | 00785093 | | Instruction manual |
| 8403 | 00785095 | | Instruction manual |
| 0222 | 00656034 | | Sealing |
| 0240 | 00749125 | | Insert |



| Position ID | Part No. | Replacement | Description |
|--------------------|-----------------|--------------------|--------------------|
| 0303 | 00747797 | | Window |
| 0306 | 00746644 | | Cover |
| 0307 | 00747795 | | Ring |
| 8401 | 00785090 | | Instruction manual |
| 8402 | 00785093 | | Instruction manual |
| 8403 | 00785095 | | Instruction manual |












| Position ID | Part No. | Replacement | Description |
|--------------------|-----------------|--------------------|----------------------------|
| 0401 | 00497211 | | Drive coupling |
| 0402 | 00657917 | | Belt-drive |
| 0403 | 00618931 | | Drum Sleeve Compl. Bearing |
| 0404 | 00652500 | | Seal set - drum support |
| 0405 | 00649045 | | Sealing |
| 0407 | 00248722 | | Drum |
| 0410 | 00652502 | 00652502 | Taper |
| 8401 | 00785090 | | Instruction manual |
| 8402 | 00785093 | | Instruction manual |
| 8403 | 00785095 | | Instruction manual |



| Position ID | Part No. | Replacement | Description |
|--------------------|-----------------|--------------------|------------------------------|
| 0501 | 00611942 | | Foot |
| 0502 | 00145534 | | Motor |
| 0503 | 00615653 | 00615653 | Spring |
| 0504 | 00600436 | | Roller-tension |
| 0505 | 00604866 | | Belt-drive |
| 0506 | 00650172 | | Fan drum |
| 0507 | 00647541 | | Fan drum |
| 0508 | 00617922 | | Capacitor-metal paper |
| 0509 | 00497214 | | Lid |
| 0510 | 00604873 | | Cover |
| 0513 | 00429372 | | Hose connection inlet |
| 0514 | 00604871 | | Cover |
| 0518 | 00753688 | | Cover |
| 0519 | 00746646 | | Cover |
| 0520 | 00746647 | | Cover |
| 0521 | 00601207 | | Lock-mechanical |
| 0522 | 00689842 | | Case-bottom |
| 0524 | 00445042 | | Insulating plate |
| 0525 | 00094041 | | Hose Fill - Condensate Water |
| 0526 | 00753646 | | Lid |
| 0527 | 00284849 | 00284849 | Drain Hose Kit |
| 0528 | 00655300 | | Holder |
| 0529 | 00416546 | | Connection |
| 0530 | 00041270 | | Cable strap |
| 0531 | 00749095 | | Lid |
| 0532 | 00753716 | | Case-bottom |
| 0534 | 00752390 | | Filter |

| | | | |
|------|----------|--|--------------------|
| 0535 | 00753649 | | Motor-protection |
| 0536 | 00700696 | | Cooler |
| 0538 | 00600543 | | Hose-fill |
| 8401 | 00785090 | | Instruction manual |
| 8402 | 00785093 | | Instruction manual |
| 8403 | 00785095 | | Instruction manual |
| 0533 | 00600528 | | Sheet |
| 0540 | 00753678 | | Insert |

| | | | | |
|---|---|--|---|---|
|  <p>0601</p> |  <p>0602</p> |  <p>0603</p> |  <p>0604</p> |  <p>0605</p> |
|  <p>0606</p> |  <p>0607</p> |  <p>0608</p> |  <p>0610</p> | |
| | | | | |
| | | | | |
| | | | | |

| Position ID | Part No. | Replacement | Description |
|--------------------|-----------------|--------------------|--------------------|
| 8401 | 00785090 | | Instruction manual |
| 8402 | 00785093 | | Instruction manual |
| 8403 | 00785095 | | Instruction manual |
| 0601 | 00630286 | | Cable harness |
| 0602 | 00630281 | | Cable harness |
| 0603 | 00630275 | | Cable harness |
| 0604 | 00630274 | | Cable harness |
| 0605 | 00630277 | | Cable harness |
| 0606 | 00630271 | | Cable harness |
| 0607 | 00630287 | | Cable harness |
| 0609 | 00630288 | | Cable harness |
| 0608 | 00630272 | | Cable harness |
| 0610 | 00630279 | | Cable harness |