CRYST⊕RAMA

0 0 0 0

 \oplus

screws x2pcs



Top cage

CAPx1pc -



IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEF ORE STARTING INSTALLATION




- Bulb


WARNING: This product can expose ...
Lead, which is known to the State of WARNING: This product can expose you to California to cause cancer and/or birth defects or reproductive harm. For more information go to www.P65Warnings.ca.gov





How to change bulb 1. Remove the 3pcs of screws on top cage.





After securing fixture to wall, it is recommended that the gap between the wall and backplate be sealed on top and both sides with a good quality waterproof caulk or silicone sealant (not included)

DUM9801GE Assembly of glass:

the cage should be taken off by removing the bottom four screws for easy replacement of glass panel If

any breakage:

