Manufacturer: Changzhou Wellife Furnace Co., Ltd.

Model: PH08-S/PH08-SS

Item: 60523

Input rate: 32400BTU/HR

Gas: Propane

Gas supply pressure:

25 to 250PSI

Manifold pressure: 11" WC



CSA INTERNATIONAL REQUIREMENT

ANSI 83.26a-2008/CSA 2.37a-2008, Gas-Fired outdoor infrared patio heater

This appliance is for outdoor use only. If stored indoors, detach and leave LPG cylinder outdoors

LIGHTING INSTRUCTIONS

Check and ensure that a AA battery is inside the ignition chamber. The anode (+) side of the battery must face out.

- Ensure the control knob is OFF and slowly open the gas cylinder valve.
- Press and turn the control knob to LIGHT.
- Check for the pilot flame through the glass tube. If the pilot does not light, turn the control knob to the OFF position and try again from the beginning. Several attempts may be necessary.
- With the pilot light lit, keep the control knob depressed (pushed down) for 15 seconds then turn the control knob LOW.
- For maximum heat, turn the control knob to HIGH.
- To turn the heater off, turn the control knob to OFF. Close the valve on your LP cylinder to conserve gas when not in use.

Serial no:

