

PARTS & ASSEMBLY SHEET

Fixture Name: Lancaster 6005-ND3 PW/RBZ/AB

This lixture assembled PO: Date:	This fixture	assembled PO:	Date:
----------------------------------	--------------	---------------	-------

Notice: Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note on this sheet and contact the place of purchase to arrange for replacement parts.

PARTS LIST	Company Name: to be filled out by retailer	Co. Account #:
Canopy lea 5"X1"	Wire connectors 2ea P3 Orange	Top loop
Chain lea 6ft x 3.8mm	Junction Box Screw 2ea 8/32" x 1"	Socket Washer 5ea ~58 x 1mm
Chain connector 2ea 4 X 55mm	Canopy Loop with Collar lea 3/8 x 30mm x 5mm	Nipple
Mounting Strap	Hex Nut 2ea 3/8 x 3mm	Srping Washer lea 15 x 3mm
Socket Ring (AB only) 3ea 51 x 23mm	Socket Ring (PW, RBZ only) 3ea 50 x 9mm	Green Ground Screw 1ea 8/32" X 10mm
Part Needed Part Needed Reason why Comments (missing, scratched)	ed, broken glass, bent, bad finish)	Quantity Quantity


FIXTURE ASSEMBLY INSTRUCTIONS

Read and review installation instruction sheet before assembling the fixture.

ASSEMBLING THE FIXTURE (Fig. 1)

- 1. Feed the fixture wires through the Top Loop (J) and pull the wires until taut.
- 2. Then screw the Top Loop (J) to the threaded center column of Frame (M) until tight.
- 3. Gently spread the arms until evenly spaced if arms are packed closed.

NOTE: INSTALL THE GLASS ASSEMBLY AFTER THE FIXTURE IS HUNG.



For Customer Service, contact the place of purchase to arrange for replacement parts.

PARTS & ASSEMBLY SHEET


Fixture Name: Lancaster 6005-ND3 PW/RBZ/AB

- 4. By measuring, determine correct number of links needed for proper hanging height. Use a pair of pliers to open one link of the Chain (K) then remove the excess Chain (K) and discard it.
- 5. Use a chain connector (L) to attach one end of the chain to the Top Loop (J) and close the chain connector.
- 6. Feed the fixture wires through the Chain (every three links) and pull the wires until taut.
- 7. Slip Canopy Loop Collar (H) over the chain, then do the same with the Canopy (G).
- 8. When ready to complete the installation, use the remaining chain connector and attach the loose end of the chain to the Canopy Loop (F). Close the chain connector.
- 9. Make sure the weight of the chandelier will be supported by the chain not the electrical wire.
 - * You may now install the fixture.

Note: Complete these remaining steps after the fixture is hung.

- 10. Place the Glass Shades (O) over the Threaded Sockets (N). Secure the Glass Shades (O) by threading the Socket Rings (Q) over the socket washers (P) until tight.
- 11. Install the light bulbs in accordance with the fixture's specifications.

(DO NOT EXCEED MAXIMUM WATTAGE RATING)



For Customer Service, contact the place of purchase to arrange for replacement parts.



INSTALLATION INSTRUCTIONS

Fixture Name: Lancaster 6005-ND3 PW/RBZ/AB

For Chandelier Light Fixture


WARNING! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.


HANGING THE FIXTURE (Fig. 1)

- Carefully remove the new fixture from the carton and the yellow bag that holds all parts. Check that all parts are included as shown in the illustration and parts list.
- 2. Shut off the power at the circuit breaker and remove the old fixture from ceiling, including the old mounting strap.
- 3. Thread Nipple (C) into Canopy Loop (F) until snug.
- 4. Thread other end of the Nipple (C) with Canopy Loop attached into Mounting Strap (D).
- Place Lock Washer (B) over end of Nipple (C) protruding through Mounting Strap (D) and thread Hex Nuts (A) onto Nipple until tight.
- 6. Take this mounting strap assembly and mount to ceiling junction box with junction box Screws (E). Tighten screws securely with screwdriver.
- 7. Unscrew the Canopy Loop Collar (H) from the canopy loop. Take the canopy and pass over the canopy loop. Approximatly half of the canopy loop exterior threads should be exposed. Adjust until desired height is reached. *The Canopy loop collar should fit snugly on the Canopy loop after the canopy is installed. Remove canopy and canopy lock collar.
- 8. Assemble the fixture and have an assistant or support the weight of the fixture while you complete the wiring connections.
- 9. Thread the fixture wires and ground wire of the assembled fixture through the canopy loop and nipple and into the outlet box.

CONNECTING THE WIRES (Fig. 2)

- 10. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED). NOTE: Twist the wires together in the same direction you twist the wire connector onto the wires.
- 11. Attach the GROUND wire (GREEN or COPPER) from the junction box and the fixture ground wire to the green ground screw on the Mounting Bracket (D).
- Or, connect both wires together using a wire connector.
- 12. Tuck these wire connections neatly into the Junction Box.
- 13. Raise Canopy (G) to the ceiling and secure in place by tightening the Canopy Loop Collar (H) into the Canopy Loop (F).
- 14. Install the light bulbs and glass shades according to the fixture assembly sheet.





YOUR INSTALLATION IS NOW COMPLETE.
RETURN POWER TO THE JUNCTION BOX
AND TEST THE FIXTURE.

For Customer Service, contact the place of purchase to arrange for replacement parts.