
HOTPOINT

RGB518PCD – Hotpoint 30" Free-Standing Gas Range

Dimensions (in inches)

30" Gas Range Installation Information (in inches)



Installation Information: Before installing, consult installation instructions packed with product for current dimensional data.

Optional gas range accessory drip pans:

(Available at additional cost) To order these accessory drip pans, call toll-free 800-626-2002.

Requires standard 9V battery




All Hotpoint ranges are equipped with an Anti-Tip device. The installation of this device is an important, required step in the installation of the range.



HOTPOINT

RGB518PCD – Hotpoint 30" Free-Standing Gas Range



Features and Benefits

- Extra-large oven capacity Ideal for special occasions and big meals, the extra large oven interior allows more to cook at once
- All purpose burners All-purpose burner delivers two levels of BTU output to accommodate virtually all your cooking needs
- Cordless Battery Ignition
- Low Battery Indicator Light
- Porcelain upswept cooktop Raised edges and porcelain-enameled surface makes cleaning incredibly easy
- Lift-up cooktop Cooktop lifts up to give you access to the subtop, where spills and crumbs can collect, to make cleaning effortless
- Easy clean subtop The subtop is porcelain enameled to make cleaning spills and messes quick and simple
- Standard grates Quality grates keep pots and pans securely in place over the burners
- Two oven racks Includes two oven racks that are sturdy and reliable
- Model RGB518PCDWH White
- Model RGB518PCDCT Bisque