
## Choosing the Right Size Ceiling Fan for your Room

Follow these steps to ensure you choose the right size fan and install it at the right height:



## Determine the square footage of your room

Measure the length of the room by the width and then multiply. For example, 12 feet long  $\times$  10 feet wide = 120 total square footage






## Have a tall or cathedral ceiling?

Many Kichler ceiling fans work with 8- or 9-foot ceilings. If your ceiling is higher, you'll need a downrod. The rule of thumb is that fans should have a minimum of 7-feet and a maximum of 9-feet of clearance between the bottom of the fan blades and the floor in order to circulate the air efficiently.



## Determine the size fan you need





Good News!

Kichler
ceiling fans
feature threaded
downrods giving your
fan added stability.