


KitchenAid®

**1.9 CUBIC FOOT MICROWAVE HOOD
(Sensor Convection)**

MODELS:

KMHP519ESS0 (Stainless)

CONTROL PANEL PARTS




CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10652354	Installation Instructions
	W10644757	Use and Care Guide
	W10644760	Quick Reference Guide
	W10644759	Tech Sheet
2		Cover, Control
	W10478239	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10533504	Duct, Cooling Front
4	W10540727	Background, Control
5	W10508739	Microcomputer
6	W10540721	Seal, Control

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10540731	Lens
2	W10509370	Control
3	W10478216	Holder, UI
4	W10540298	Plate, UI Insulation
5	W10617743	Cover, UI
6	W10476546	Bracket, Door
7	W10604264	Assembly, Handle
8	W10540736	Cushion, Handle
9		Cover, Screw
	W10478657	Black
10		Bracket, Outer Door
	W10478656	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10568846	Body, Door (With Glass)
12	W10489272	Hooks, Door
13	W10542546	Cover, Screw
14		Frame, Back Decorating
	W10476550	Black
15	W10643448	Stopper, Door
16	W10478653	Frame, Inner
17		Assembly, Door Frame
	W10688550	Stainless
18	W10688553	Glass, Door
19	W10478659	Holder, Door Cable

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20	W10508745	Wire, Door Control
		Cable
21		Badge
	W10518673	Stainless
22	W10478230	Bracket, Door Cable
23	W10509362	Cable, Sensor
24	W10478647	Plate, Steam Protection
25		Door, Complete
	W10711113	Stainless


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10540723	Chassis	15	W10536989	Thermistor PCBA	30	8206223	Clip
2	W10208564	Lamp, Halogen	16	W10510235	Tube, Smart Pop Sound	31	W10508748	PCBA, Smart Pop
3	W10525853	Terminal, Smart Pop	17	W10510234	Terminal, Smart Pop	32	W10631701	Magnetron, Air Guide
4	W10535933	Filter, Grease	18	W10568805	Resistor, Cement	33	W10536556	Motor, Cooling
5	W10607242	Plate, Bottom	19	W10211974	Switch, Micro	34	W10533503	Wheel, Cooling Fan
6	W10240330	Assembly, Lamp Glass and Holder	20	W10245194	Holder, Fuse	35	W10533486	Valve, Door
7	W10510237	Spacer, Smart Pop	21	W10138793	Fuse	36	W10533501	Housing, Cooling Fan
8	W10269457	Microswitch	22	W10591803	Thermostat, Magnetron	37	W10533502	Cover, Cooling Fan
9	W10269458	V15T16-CZ200/NC/NO Microswitch	23	W10711112	Transformer, High Voltage	38	W10533480	Holder, NTC
10	W10156812	V15T16-CC200/NC Spring, Interlock	24	W10556823	Bracket, Capacitor	39	W10458325	Actuator
11	W10156811	Plate, Cam	25	W10561774	Capacitor, High Voltage	40	W10533107	Deflector, Air
12		Support, Interlock	26	W10575765	Diode, High Voltage	41	W10571453	Insulation, Side
	8206419	Top	27	W10510233	Terminal, PCBA Smart Pop	42	W10540718	Bracket, Cavity
	W10156813	Bottom	28	W10259248	Cover, Thermostat			
13	W10197758	Assembly, Piston	29	W10599629	Thermostat, Convection			
14	W10605897	Capacitor, Hood Motor						

AIR FLOW PARTS




AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10631698	Deflector, Air
2	8206382	Cover, Lamp
3	W10557536	Sensor, Humidity
4	4393681	Lamp, Cavity 30 Watt
5	W10533487	Plate, Air Guide
6	W10479847	Motor, Fan
7	W10556824	Housing, Damper
8	8206230	Filter, Charcoal
9	W10571180	Seal, Foam
10	W10654514	Thermostat, Cavity

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10557537	Sensor, Convection
12	W10210878	Holder, Lamp Cavity
13	W10632409	Baseplate, Air Guide
14	W10533484	Cover, Duct (Right)
15	W10572027	Board, Filter
16	W10139750	Socket, Motor Wire
17	W10533112	Outlet, Cavity (Back)
18	W10711110	Magnetron

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10533113	Duct, Cavity (Rear)
20	W10627070	Duct, Cavity (Front)
21	W10629803	Shield, Finger (Includes Seal)
22	W10531724	Glass, Lamp
23	W10652714	Assembly, Air Guide Grill
24	W10565479	Board, Door Control


TURNTABLE PARTS



TURNTABLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10533498	Cover, Waveguide	9	8184109	Seal, Waterproof	17	W10367384	Plate, Crisp
2	W10626726	Hook, Microwave (Left Front & Right Front)	10	W10440082	Rack, Convection	18	W10461761	Handle, Crisp Plate
3	W10660052	Steamer	11	W10568148	Seal, Turntable Block			
4	W10531726	Turntable	12	W10573936	Hook, Microwave (Left Rear & Right Rear)			
5	W10570257	Ring, Turntable	13	W10689508	Reflector, Grill			
6	W10337248	Driver, Turntable	14	8184837	Element, Grill Halogen			
7	W10466420	Motor, Turntable	15	W10510203	Heater, Quartz Grill			
8	W10637931	Rack, Microwave	16	8206264	Rack, Grill			

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10440498	Plate, Mounting
2	8206442	Damper
3	W10654511	Cord, Power
4		Case, Outer
	W10571408	Black
5		Grille, Vent
	W10701701	Black
6	W10625423	Cover, Fan Motor
7	W10571554	Assembly, Convection Motor and Fan
8	W10533488	Duct, Cooling (Upper)
9	W10533489	Duct, Cooling (Bottom)
10	W10570212	Duct, Air Turntable Motor
11	W10596040	Assembly, Mounting Nut
		Following Parts Not Illustrated
	W10571450	Insulation, Back
	W10571451	Insulation, Top
	W10571454	Insulation, Bottom
		Miscellaneous Parts
	8206614	Installation, Hardware
	W10190018	Template, Upper
	8169704	1/4-20x3" Panhead Screw
	W10711111	Harness, Main
	W10530090	Harness, Headlamp and Turntable
	W10532916	Harness, Bottom Lamp
	W10670896	Harness, Fade In / Fade Out
	W10566563	Harness, Smart Pop
	W10539840	Harness, PCBA Ground Wire
	W10566562	Cable, Fade In / Fade Out
	W10508741	Wire, Door Control Cable