


KitchenAid®

42" SIDE BY SIDE BUILT IN REFRIGERATOR

MODELS:

KBSD602ESS00 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	2257644	Hinge, Top	32	487415	Screw
	W10763009	Use and Care Guide	16	W10674648	Bracket, Filter	33	486194	Screw
	W10763004	Energy Guide	17	W10001250	Screw	34	2006617	Bracket, Base Support (Rear)
	W10763010	Installation Instructions	18	2004994	Lock, Bushing	35	2215938	Cover, Switch
		Tech Sheet	19	W10484913	Bushing, Top Hinge	36	2316859	Bushing, Extension Arm
	W10762990	English	20	2221242	Spring, Door Closure (Green)	37	W10780213	Assembly, Switch Wire
	W10762992	French	21	3400230	Screw	38		Button, Water Filter
2		Cabinet (Not Serviced)	22	2005008	Ring, Bushing Retaining		2260503B	Black
3	2318189	Tray, Filter Drip	23	2215612	Cover, Air Duct	39	1118894	Switch, Rocker Arm
4	W10138054	Assembly, Roller	24		Bracket, Switch		1115373	Switch, Rocker Arm Combination (Freezer)
5		Assembly, Support Base		W10741112	Left Hand	40	8281163	Screw (Stainless)
	W10279275	Left Hand	25		Hinge, Bottom	41	W10005050	Screw
	W10138423	Right Hand		2006779	Left Hand	42	W10271541	Connector, Union
6		Cap, Water Filter		2006780	Right Hand	43	W10663352	Clip
	2260518B	Black	26	2302876	Bushing, Adjustable	44		Bracket, Support
7	2307640	Bracket, Grill Mounting	27	8533913	Screw		2006616	Left Hand
8	2320509	Stop, Door	28		Skirt, Bottom Grille		2006556	Right Hand
9	W10121140	Housing, Water Filter		W10188549	Black	45	W10141604	Screw
10	2307584	Grommet, Crossover Tube	29		Arm, Extension	46	2005032	Leveler, Adjustable
11	3400525	Screw		W10709785	Left Hand	47	2314064	Tube, Drain
12	W10121146	Filter, Water		W10728112	Right Hand	48	2006841	Ring, Retainer
13	8281164	Screw (Stainless)	30		Grille, Bottom			
14	W10485630	Screw		W10182717	Black			
			31	W10485630	Screw			


CABINET TRIM PARTS



CABINET TRIM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side Right Hand W10568005 Aluminum	4		Trim, Bottom Cabinet 2316687 Aluminum	7		Trim, Cabinet Side Left Hand W10568007 Aluminum
2	W10001250	Screw	5	486194	Screw	8	W10121451	Insert, Blind Threaded
3	2005925	Seal, Side Trim	6		Trim, Top Cabinet 2314017 Aluminum			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not Serviced)	17	2221296	Assembly, Air Baffle	28		Slide, Meat Pan
2	2306010	Thermistor	18	2309222	Assembly, Air Diffuser		2302954	Left Hand
3	2208970	Duct, Air	19	W10607479	Assembly, LED Module	29	2302955	Right Hand
4	487539	Screw (Stainless)	20	2310205	Assembly, Meat Pan Wire			Spacer, Crisper
5	2259077	Ladder, Shelf	21	W10159487	Diverter, Crisper Cover		2256223	Left Hand
6	520965	Support, Ladder	22	W10798004	Assembly, Control Box	30	2256222	Right Hand
7	2006475	Screw (White)	23	2317000	Clip, Control Box			Slide, Crisper
8	2309087	Cover, Air Diffuser	24	8281163	Screw (Stainless)		2302956	Left Hand
9	2302937	Thermistor	25	W10760791	Assembly, User Interface	31	2302957	Right Hand
10	W10475010	Assembly, Spacer	26	W10142283	Screw (White)			Screw
11	W10169528	Assembly, Control Baffle	27		Spacer, Meat Pan		8533928	Screw (Stainless)
12	W10645131	Reservoir, Water		2256243	Left Hand			Right Hand
13	2188820	Thermistor		2256244	Right Hand		8533929	Screw (Stainless)
14	8533929	Screw (Stainless)				32	W10141518	Screw
15	486194	Screw				33	2003577	Guard, Air Return
16	2317844	Assembly, Thermistor						


FREEZER LINER AND AIR FLOW PARTS



FREEZER LINER AND AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	17	2307774	Duct, Air	31	W10173127	Assembly, Shelf Stud
2	2198665	Tube, Circuit Board	18	2198643	Lens, Receiver	32	8281163	Screw (Stainless)
3	2169142	Blade, Fan	19		Block, Fan Scroll	33		Rail, Evaporator Cover
4	W10260421	Retainer, Fan Motor		2209066	Left Hand		2221107	Left Hand
5	2302817	Gasket, Scroll Assembly		2209480	Right Hand		2259355	Right Hand
6	W10321090	Grommet, Motor	20	2215650	Cover, Emitter	34	2220904	Gasket, Evaporator Cover
7	486194	Screw	21		Liner (Not Serviced)	35	2259493	Cover, Receiver
8	2259464	Wedge, Right Air Duct	22	W10160570	Bi-Metal, Defrost	36	W10482187	Harness, Bi-Metal Wire
9	487539	Screw (Stainless)	23	2259025	Cover, Air Outlet	37	2306010	Thermistor
10	W10607479	Assembly, LED Module	24	2198633	Flipper, Shut Off	38	2317844	Assembly, Thermistor
11	W10290817	Board, Receiver Circuit	25	W10581992	Assembly, Evaporator Cover	39	2006475	Screw (White)
12	2317105	Cover, Thermistor	26	2302850	Support, Air Duct	40	2259032	Ladder, Shelf
13	489214	Screw	27	W10581988	Gasket, Evaporator Cover	41	2259445	Support, Ladder
14	2182120	Scroll, Fan	28	2198635	Spring, Door	42	2198634	Pin, Door
15	2259465	Wedge, Left Air Duct	29	2255563	Slide, Icemaker Shut Off	43	W10193840	Board, Emitter Circuit
16	W10142283	Screw (White)	30	1112260	Support, Evaporator			








MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222965	Bin, Ice	7	8281163	Screw (Stainless)	12	2315547	Motor, Dispenser
2	W10134774	Bin, Crusher	8	2188919	Clip, Shaft	13	2318028	Cover
3	W10749207	Button, Bin	9	2198628	Seal	14	W10254073	Washer
4	W10134783	Latch, Bin	10	2318082	Shaft, Drive	15	W10769115	Assembly, Ice Container
5	2198608	Spring, Latch	11	2318011	Enclosure, Motor			
6	2198671	Screw (Stainless)						


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10568584	Assembly, Shelf	5	W10407627	Assembly, Meat Pan	8	W10701859	Rack, Wine
2	W10407624	Pan, Crisper	6	2256248	Front, Crisper Pan	9	W10593207	Assembly, Produce Preserver
3	W10556312	Assembly, Meat Pan Cover	7	2256366	Front, Meat Pan			
4	W10556775	Assembly, Crisper Cover						

FREEZER SHELF PARTS




FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10759084	Shelf, Wire
2	W10759069	Shelf, Fixed
3	2259082	Basket, Freezer
4	2256270	Front, Basket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259318	Left Hand
	2259317	Right Hand
6	8533928	Screw (Stainless)


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10761878	Door, Refrigerator	11		Handle, Door	19		Endcap, Utility Bin
2	2006346	Washer, Extension Arm		W10541592	Stainless		W10323173	Left Hand
3	W10485980	Assembly, Hinge (Top)	12	W10758113	Spacer, Handle Side Door		W10323172	Right Hand
4	2316804	Spacer, Door Hinge Bottom	13	488568	Screw (Stainless)	20	W10323036	Bin, Center Utility
5	W10162602	Screw	14	8281250	Screw (Stainless)	21	2257616	Door, Utility Bin
6	2302878	Assembly, Bottom Hinge	15	W10761896	Spacer, Door Skin (Top)	22	W10323599	Bin, Shallow Door
7	2222796	Rail, Lid	16	W10756209	Spacer, Hinge Side Door	23	W10323747	Bin, Gallon Door
8	2222982	Gasket, Utility Bin	17	W10761936	Spacer, Door Skin Bottom	24	W10127710	Plate, Handle Door
9		Gasket, Door	18	W10482554	Cover, Bottom Gap	25	308544	Screw
	W10764832	Grey						
10		Skin, Door						
	W10756461	Stainless						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u>			<u>Illus.</u>			<u>Illus.</u>		
<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10775462	Assembly, Freezer Door (Includes Dispenser Parts)	8		Handle, Door	15	W10756209	Spacer, Hinge Side Door
2	W10127710	Plate, Handle Door		W10541592	Stainless	16	308544	Screw
3	2302879	Assembly, Bottom Hinge	9	W10758113	Spacer, Handle Side Door	17	W10482554	Cover, Bottom Gap
4	W10162602	Screw	10		Skin, Door	18	W10323602	Bin, Shallow
5	W10485980	Assembly, Hinge (Top)		W10756219	Stainless	19	2006346	Washer, Extension Arm
6	2316804	Spacer, Door Hinge Bottom	11	8281250	Screw (Stainless)			
7	W10761964	Gasket, Door Grey	12	W10758117	Spacer, Door Skin (Top)			
			13	488568	Screw (Stainless)			
			14	W10758119	Spacer, Door Skin Bottom			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	9	2305235	Assembly, Spigot	15	2305219	Cover, Control
2	8281163	Screw (Stainless)	10	2318017	Assembly, Separator	16	2321746	Assembly, User Interface Control Cover
3	W10542660	Bracket, Motor	11		Housing, Middle (Not Available Order Item 12)	17	W10151236	Assembly, User Interface
4	W10546285	Assembly, Motor and Bracket	12	W10260622	Assembly, Housing	18		Housing, Tray
5	W10205979	Motor, Ice Door	13		Assembly, Water Paddle	2318062US		Universal Silver
6	W10504458	Door, Ice		2305307GN	Universal Silver	19	2305342	Assembly, LED
7	W10542663	Support, Ice Door	14		Assembly, Ice Paddle			
8	4449745	Screw		2305306GN	Universal Silver			


TOP GRILLE AND UNIT COVER PARTS



TOP GRILLE AND UNIT COVER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille	3	1157158	Screw	6		Nameplate
	W10761968	Stainless	4	2256466	Panel, Unit Back		W10518672	Grey
2	W10545068	Cover, Unit	5	W10694109	Cover, Unit Front			


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645666	Assembly, Inverter Box	17	W10775849	Assembly, Unit Wire	34	2310196	Cord, Power
2	489373	Screw	18	W10761479	Plate, Circuit Board	35	W10321055	Bracket, Control Assembly
3	W10653005	Compressor	19	W10635302	LED Control	36	549193	Clamp, Power Cord
4	W10550831	Housing, Control Board Mounting	20	2155774	Tie, Wire	37	W10648264	Tube, Heat Loop Transition
5	W10587113	Grommet	21	W10175593	Drier	38	2318054	Control, Electronic
6	1100826	Grommet	22	W10414681	Bracket, Fan Motor	39	W10770059	Plate, Circuit Board (Top)
7		Support, Condenser	23	2188875	Motor, Condenser			Following Parts Not Illustrated
	W10525179	Right Hand	24	W10139483	Blade, Fan		978025	Valve, Access
8	2259350	Board, Power Supply	25	W10415670	Orifice, Fan		978026	Valve, Access
9	2215676	Cover, Terminal	26	487294	Screw		978027	Valve, Access
10		Support, Condenser	27	W10146359	Screw		978028	Valve, Access
	W10525177	Left Hand	28	2266802	Switch, Power Disconnect		978029	Valve, Access
11	W10200659	Control, Electronic	29	2310195	Assembly, Jumper Wire (Power Switch to Power Cord)		978030	Valve, Access
12	2203075	Spacer	30	W10624944	Tube, Drier Transition		876764	Valve, Access
13	2256328	Bracket, Inverter Mounting	31	W10528578	Tube, Process			REFRIGERANT CHARGE
14	W10624574	Supply, Power	32	486194	Screw			6.75 oz. (R-134A)
15	1157158	Screw	33	W10525175	Cover, Condenser Support			
16	W10591457	Condenser						

LOWER UNIT AND TUBE PARTS




LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10160981	Assembly, Air Return Bracket
2	W10388653	Tube, Transition (Drier/Restrictor)
3	486194	Screw
4	W10157752	Bracket, Heater
5	W10648568	Tube, Oil Trap Suction
6	W10281063	Assembly, Drain Pan
7	W10309012	Cover, Wiring

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10321048	Cover, Wire Box
9	W10499596	Tube, Discharge
10	W10321050	Shelf, Wiring Cover
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10413009	Grommet, Air Return
15	W10139908	Cover, Evaporator Seal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10432308	Gasket, Evaporator
17	2155774	Tie, Wire
18	W10169509	Clip, Heat Exchanger
19	2320554	Support, Drain Pan
20	2215648	Dampener
21	304392	Screw

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	304392	Screw	16	W10377998	Cup, Fill	32	W10001250	Screw
2	2320601	Shield, Water Valve	17	627843	Ejector	33	2198641	Bracket, Icemaker Cover
3	628379	Clip, Thermal Fuse	18	W10272161	Stripper, Ice	34	487539	Screw (Stainless)
4	W10296807	Tube, Filter Inlet	19	2194712	Support, Housing	100	W10774430	Complete Icemaker Assembly
5	W10357286	Fitting, Water	20	2315522	Retainer, Thermostat			Following Parts Not Illustrated
6	487294	Screw	21	627985	Thermostat	W10355016		Cleaner, Stainless Steel
7	W10683737	Tube, Filter Outlet	22	W10001280	Screw	W10355049		Wipes, Stainless Steel Cleaning
8	W10159842	Valve, Inlet	23	W10279391	Assembly, Smart Valve Wire	W10355010		Cleaner, Kitchen & Appliance
9	2221070	Clamp, Tube	24	489276	Screw			
10	2320559	Support, Valve	25	W10504753	Cover, Icemaker			
11	2208136	Clip, Water Tube	26	W10223929	Assembly, Module and Motor			
12	W10141645	Screw	27	489136	Screw			
13	W10289690	Cover, Icemaker	28	W10129069	Clip, Wire			
14	628228	Assembly, Mold and Heater (Also Order 542638)	29	486194	Screw			
15		Motor (Not Serviced, Order Item 26)	30	2252228	Bracket, Icemaker Mounting			
			31	W10508659	Assembly, Icemaker Wire			