


**KitchenAid®**

**27" BUILT-IN ELECTRIC SINGLE WALL OVEN WITH CONVECTION**

**MODELS:**

KOSE507EBL00 (Black)  
KOSE507EWH00 (White)  
KOSE507ESS00 (Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	7101P426-60	Screw	16	W10694466	Chassis, Cover Top
	W10643471	Guide, Use & Care	9	7101P434-60	Screw			Back 27"
	W10725670	Instructions, Installation	10	W10655463	Bracket, Blower (Left)			FOLLOWING PARTS
	W10756610	Sheet, Tech		W10655462	Bracket, Blower (Right)		W10632451	Harness, Main
2		Assembly, Control Panel (Includes Overlay)	11	4451758	Block, Foam		W10603909	Harness, Signal
	W10588709	Black	12		Skin, Control Panel		W10573327	Harness, Door Latch
	W10588715	White		W10588745	Black		W10562910	Harness, EOL
	W10588712	Stainless		W10588747	White		4450800	Screw, Grounding
3	W10777215	Control (With Power Supply)		W10588741	Stainless		313438	Clip, Harness
4	W10618105	Spacer, Lateral	13	W10694467	Tray, Electronic		4452400	Strap, Lead Ground
5	W10669823	Blower	14	W10655465	Chassis, Back Divider		4448664	Clamp, Conduit
6	W10671226	Gasket, Rubber	15	W10318193	Chassis, Cover Top Front 27"		W10655464	Bracket, Harness
7	W10436434	Fuse, Thermal						

# OVEN PARTS




# OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10318196	Duct, Chassis Back
2	W10282946	Tube, Vent
3	W10616802	Receiver, Hinge
4	W10618102	Spacer, Base
5	W10314880	Latch, Motorized
6	W10730173	Top, Chassis
7	W10519866	Assembly, Oven Light
8	W10618101	Foot, Base
9	W10641572	Deflector, Blower
10	W10254050	Screw
11	W10282961	Gasket
12	W10616810	Cover, Vent Exhaust
13	W10318190	Side, Chassis
14	W10696136	Back, Chassis
15		Liner, Oven (Not Serviceable)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10622170	Probe, Sensor
17	W10351278	Bumper & Screw
18	4449751	Thermostat (TOD)
19	W10282901	Base, Chassis
20		Assembly, Bottom Vent
	W10351276	Black
	W10506349	White
	W10327376	Stainless
21	W10283008	Chassis, Bottom Duct
22		Trim, Bottom Vent
	W10351237	Black
	W10504025	White
	W10327378	Stainless
23	W10213759	Support, Air Channel
24	W10351308	Spacer, Chassis Bottom Duct

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	W10283037	Vent, Top 27"
26	8285593	Cover, Connector
27	7101P426-60	Screw
28	W10472386	Lens, Light
29		Cover, Side Trim
	W10344481	Black (Left)
	W10344480	Black (Right)
30	W10618106	Spacers, Front
31	W10472384	Bulb, Light
32	W10616809	Base, Vent Exhaust
		Following Parts Not Illustrated
	W10520716	Insulation, Wrap
	W10282945	Insulation, Back

# OVEN DOOR PARTS




# OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10347597	Assembly, Window Pack
2	W10284285	Spring, Door Glass Fixation
3	3196183	Screw
4		Badge
	W10518672	Grey
5	W10320793	Assembly, Liner
6	W10639067	Hinge, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7		Assembly, Door
	W10615246	Black
	W10615247	White
	W10615245	Stainless
8		Assembly, Handle
	W10640874	Stainless
9	W10284902	Glass, Inner
10	W10284297	Bracket, Glass
11	W10656499	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	7101P426-60	Screw
13	7101P633-60	Screw (Black)
14	W10653954	Clip, Spring Metal
15	W10687815	Extension, Side Rail (Left)
	W10687814	Extension, Side Rail (Right)
16	W10669415	Shield, Door Liner

# INTERNAL OVEN PARTS





# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10764078	Element, Broil
2	W10554529	Rack, Oven
3	W10318198	Tray, Hidden Bake
4	7101P376-60	Screw
5	7101P426-60	Screw
6	W10282957	Crossbar, Hidden Bake Tray
7	W10546517	Element, Bake

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10722667	Fan, Convection
9	W10631504	Nut, Acorn
10	W10631503	Blade, Fan
11	W10546519	Element, Convection
12	W10359277	Baffle, Bow Tie
13	W10318164	Shield, Broil Element
14	W10588738	Shield, Broil Front

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10524044	Jack, Meat Probe
16	9755547	Washer, Lock
17	9755546	Nut, Hidden
18	W10554532	Rack, Sliding
19	9755542	Probe, Temperature

# OPTIONAL PARTS

## **PAINT, TOUCH-UP (1/2OZ.)**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

## **PAINT, SPRAY**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque
	350956	Almond
	350942	White Primer
	350938	Gray Primer

## **ACCESSORIES**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10355016	Cleaner, Stainless Steel
	W10355010	Cleaner, Kitchen & Appliance
	W10355049	Wipes, Stainless Steel Cleaning

## **ADHESIVE**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic