#### **Canister (Single-Flush) Toilets**

CLASS SIX, KOHLER.
CLASS FIVE.

If you have a single-flush canister toilet, you will not see a flapper in the tank but a cylinder-shaped flush valve. These toilets do not use a flapper, but a seal. If your toilet is leaking water into the bowl, the seal needs to be replaced, not the flush valve.



## Canister (Single-Flush) Toil

### Canister (Single-Flush) One-Piece Toilets KOHLER₀ Genuine Parts

| NOTICE IS ACTUME 1 arts |                            |                      |                             |             |                    |                                    |  |  |  |  |
|-------------------------|----------------------------|----------------------|-----------------------------|-------------|--------------------|------------------------------------|--|--|--|--|
| Float/Fill Valve        | Discontinued<br>Fill Valve | Flush Valve          | Discontinued<br>Flush Valve | Tank Gasket | Flush Ball/Flapper | Discontinued<br>Flush Ball/Flapper |  |  |  |  |
| GP1083167               | N/A                        | 1.28 gpf<br>1159786  | N/A                         | N/A         | GP1059291          | N/A                                |  |  |  |  |
| GP1083167               | N/A                        | 1.28 gpf<br>11551540 | N/A                         | N/A         | GP1059291          | N/A                                |  |  |  |  |
| GP1083167               | N/A                        | 1.28 gpf<br>11551540 | N/A                         | N/A         | GP1059291          | N/A                                |  |  |  |  |
| GP1083167               | N/A                        | 1.28 gpf<br>1151540  | N/A                         | N/A         | GP1059291          | N/A                                |  |  |  |  |

# Canister (Single-Flush) Toile

### Canister (Single-Flush) Two-Piece Toilets KOHLER₀ Genuine Parts

| KOHLER® Genuine Parts |   |  |                             |   |                    |                                    |  |  |  |  |
|-----------------------|---|--|-----------------------------|---|--------------------|------------------------------------|--|--|--|--|
| Float/Fill Valve      | Discontinued<br>Fill Valve                          | Flush Valve  | Discontinued<br>Flush Valve | Tank Gasket                                   | Flush Ball/Flapper | Discontinued<br>Flush Ball/Flapper |  |  |  |  |
| GP1083167             | N/A   | 1.28 gpf<br>1151739<br>1.6 gpf<br>1070282  | N/A                         | GP1018165-F<br>1024390                        | GP1059291          | N/A                                |  |  |  |  |
| GP1083167             | N/A   | 1.28 gpf<br>1157702  | N/A                         | GP51487                                       | GP1059291          | N/A                                |  |  |  |  |
| GP1083167             | N/A   | 1.28 gpf<br>1161447  | N/A                         | GP51487                                       | GP1059291          | N/A                                |  |  |  |  |
| GP1138930             | DISCONTINUED Use GP1138930  1096382 1034694 1059495 | 1.28 gpf<br>1113628<br>1.28 gpf<br>1142634<br>(for lined tank)<br>1.6 gpf<br>1083980 | N/A                         | 1112256<br>2"<br>GP1018165-F<br>3"<br>1024390 | GP1059291          | N/A                                |  |  |  |  |
| GP1083167             | N/A   | 1.28 gpf<br>1157995<br>1.6 gpf<br>1126916  | N/A                         | GP51487<br>1.28 gpf                           | GP1059291          | N/A                                |  |  |  |  |
| GP1083167             | DISCONTINUED Use GP1083167  1085759 1083167         | 1.28 gpf<br>1090618<br>1.6 gpf<br>1085760  | N/A                         | GP1018165-F<br>1024390                        | GP1059291          | N/A                                |  |  |  |  |