


## **Replacement Parts**

Keep this manual for ordering replacement parts.



## NO NAME

- 1. Sprayer
- 2. Black nylon hose
- 3. Locating sleeve
- 4. Steel ring
- 5. Spout
- 6. Anti-friction ring
- 7. Plastic retainer ring
- 8. O-ring
- 9. Plastic retainer ring
- 10. Noise silencer
- 11. Screw
- 12. Faucet body
- 13. Cartridge
- 14. Locking nut
- 15. Cartridge cover
- 16. Handle knob
- 17. M6 screw
- 18. Handle bar
- 19. Bottom rubber
- 20. Flat gasket
- 21. Locking rubber
- 22. Locking gasket
- 23. Screw
- 24. Locking gasket
- 25. Locking nut
- 26. Nut
- 27. Spring
- 28. Sleeve
- 29. Plastic stop collar
- 30. Hose
- 31. Sleeve nut
- 32. Check valve
- 33. Flat gasket
- 34. Sleeve
- 35. Flat gasket

