LED Exterior Ceiling



START FROM HERE


- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- · Wear gloves at all times during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage

- **1.** Remove fixture from its original package.
- **2.** Separate fixture body **(2a)** from mounting plate **(1c)** by removing set screws with allen key **(2f)**.
- **3.** Attach mounting plate (1c) to electrical junction box (1a) using junction box screws provided (1e) in hardware package.
- **4.** Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts **(1b)** provided in hardware package.
- **5.** Attach fixture body (2a) to mounting plate (1c) with set screws and allen key (2f).
- **6.** To prevent moisture from entering the electrical junction box (1a) and causing a short, seal around the top perimeter between the fixture and the surface with weather resistant caulking (Illustration 1).



PRODUCT ID	PART
1e.	XHPP832-8
2f.	XHSSM5-14
LED Driver	XDR-HEP-LSC9-500-UNV-ND
Allen Key	XHAK-M5



