


Note: Please check your print settings and make sure it is set to “Actual size”.

Hint: To save ink, change print settings to “grayscale” and change the print quality to “fast draft”.

Fixture dimensions: 25”W x 7”H



A



B



C



D

