


# Assembly Instructions For **10194** (E) 7/2012



## **READ ALL INSTRUCTIONS BEFORE ASSEMBLING LAMP**

Carefully unpack lamp parts onto carpeted surface or blanket and identify all parts.

1. Install bulb (not included). See relamping label located at socket area for type and maximum allowed wattage.
2. Turn the knob to loosen the stem. Then adjust the height of the lamp and tighten the knob once the desired height has been established.

### **IMPORTANT SAFETY INSTRUCTIONS:**

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

**FEISS**<sup>®</sup>

EST. 1955