

# **Installation And Safety Instructions**

HC-1430

081908

Line art shown may not exactly match the fixture enclosed. However, the installation instructions do apply to this fixture. Fill in Item Number on Carton and File This Sheet For Future Reference. ITEM#\_\_\_\_\_

### **IMPORTANT SAFETY INSTRUCTIONS**

- Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off.
- Use of other manufacturers components will void warranty, listing and create a potential safety hazard.
- If you are unclear as to how to proceed, contact a qualified electrician.
- · You don't need special tools to install this fixture.
- Be sure to follow the steps in the order given.
- Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling which contains a radiant type heating system.
- Read instructions carefully.
- · Save these instructions.

#### **CLEANING**

To clean, wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

#### **ORDERING PARTS**

Keep this sheet for future reference, and in case you need to order replacement parts. Parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.

#### **BEFORE YOU BEGIN**

Carefully remove the fixture from the carton and check that all parts are included, as shown in figure 1. Be careful not to misplace any of the screws or parts which are needed to install this fixture.

#### **INSTALLATION**


IMPORTANT: DO NOT ATTACH FIXTURE DIRECTLY TO OUTLET BOX.

# STEP 1:

Insert fixture mounting screws (F) into universal mounting bar (D) and run fixture mounting screws (F) all the way down to the heads.

## STEP 2:

Using outlet box screws (not supplied) fasten universal mounting bar (D) to outlet box through slots in universal mounting bar (D). Make sure fixture mounting screws (F) are perfectly horizontal so fixture hangs straight.



# **INSTALLATION** (continued)

HC-1430

# STEP 3:

- **A.** Use a listed connector to connect the fixture hot wire (black wire, or round and smooth tracer) to the supply hot wire.
- **B.** Use a listed connector to connect the fixture common wire (white wire, or square and rigid) to the supply common wire.
- **C.** Gently try to remove the wires from the connector. If you can remove the wires, carefully re-do the wiring connection.

# STEP 4:

**GROUNDING INSTRUCTIONS:** The green grounding screw (G) is to be inserted into the hole with two raised dimples provided on the universal mounting bar (D). Wrap the ground wire from the fixture (H) and the ground wire from the outlet box (bare metal or green insulated wire) around the green grounding screw (G) on the universal mounting bar (D) and tighten the green grounding screw (G) to secure. **NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.** 

# **FINAL ASSEMBLY**

## STEP 5:

Make sure no bare wires can be seen outside wire connectors. After wires are connected, tuck them carefully inside outlet box. Push the fixture firmly over the mounting screws (F) and against the wall. Secure canopy (I) in place with cap nuts (E).

# STEP 6:

Place shade (A) on socket cup (B) and secure by threading retaining ring (C) onto socket.

## STEP 7:

Install lamps (not supplied).

