CEELEY TEMPERED GLASS SHELF

BEFORE INSTALLING


Read the installation instructions below. Observe all local building and safety codes.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages and ensure that none of the required pieces are missing. If you find damages, do not install. Contact Customer Service at 1.855.715.1800. If you need assistance or have questions while installing your glass shelf, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the shelf or wall, or for personal injury during installation.

TOOLS AND MATERIALS:



INSTALLATION

1. Hold one of your glass shelves up to the wall to determine the installation location. Using a level and pencil, draw a light line on the wall the length of the shelf.

2. Slide the rail through the center rail holder. Attach left and right rail holders to rail.

3. Attach the rail to the glass shelf using supplied screws and washers.




4. To mark the escutcheon placement, find the center point of the line that you drew on the wall. Make two marks to the right and left of the center, at an equal distance. The escutcheons should be 1-2" in from the outer edges of the glass shelf.

5. Hold the mounting brackets up to the wall directly on top of the escutcheon guidelines created in the previous step. Use the screw holes in the mounting brackets to mark your drilling location.

6. Use a drill bit that corresponds to the size of the included screws to drill your mounting holes.





CEELEY TEMPERED GLASS SHELF

7. Place the escutcheon onto the installed mounting brackets and secure the set screws with supplied Allen wrench.

8. Insert the glass shelf and tighten the set screws with the supplied Allen wrench to secure.





customer service: 1.855.715.1800 signature**hardware**.com