

ASSEMBLY INSTRUCTIONS


STYLE# 22064

Careful unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off.
3. Determine the **Rods** to be assembled according to your desired hanging height. Hand tighten until snug.
4. Place the **Ceiling Canopy** over the **Mounting Screws** and thread **Mounting Balls** onto the **Mounting Screws** to secure it, Hand tighten until snug.
5. Pass the Supply Wires with Ground Wire through the **Swivel** and **Canopy**. Thread the **Swivel** into the top end of the **Upper Rod** and hand tighten until snug.
6. Tread the **Coupling** into the end of the lower **Rods** and hand tighten until snug
7. Place **Diffuser**, **Rubber Washer** and **Flat Washer** onto the **Stem**, secure by thread **Hex Nut** onto **Stem**.
8. Thread the **Finial** onto the end of the **Stem** and hand tighten until snug.
9. Install bulbs (not included). See label located at socket area for type and maximum allowed wattage.

Your installation is completed now. Restore electricity.

Retain this sheet for future reference !



PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151

www.uttermost.com