

INSTRUCTIONS : HR-1136 and HR-1137 Miniature Low Voltage Recessed Fixtures

CAUTION :

To reduce the risk of fire, electrical shock and injuries to persons :

- Use only insulated staples or plastic ties to secure cords.
- Route and secure cords so they will not be pinched or damaged when cabinet is pushed to the wall.
- Position cabinet light with respect to cabinet so as to permit reading of lamp replacement marking during relamping.
- Not intended for recessed installation in ceilings.

1. Cut a 2 3/8" diameter opening on the mounting surface.
2. Unscrew nut on top of fixture to remove can.
3. Connect "output" wires from the transformer to the socket wires with wire nuts provided.
4. Place lens and secure lamp in place.
5. Insert lamp into the porcelain socket.
6. Push the trim up against the can and secure with nut.
7. Insert fixture into the opening.

Note: This fixture is designed for use with an MR11 lamp of 12V, 35W or less.

