





Fixture Name: Hampden 6262-SF DNI

This fixture assembled PO: _____ Date: _____

Notice: Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note on this sheet and contact the place of purchase to arrange for replacement parts.

PARTS LIST		Company Name: _____ Co. Account #: _____ to be filled out by retailer	
Canopy 1ea Ø5-1/2"*H1-1/4"		Mounting screws 2ea 8#32-IP*1"	
Chain 6ft Ø3.8		Wire connectors 3ea P3 Orange	
Chain connector 2ea Ø5.8*H61mm		Canopy loop with Collar 1ea Ø1-1/8"*H42mm	
Circular mounting strap 1ea Ø4"*H2mm		Deco nut 2ea 5/32-IP*H10mm	
Mounting screws 2ea 5/32-IP*1-3/4"		Frame ring 1ea Ø16-1/4"*H42mm	
Top loop 1ea 1/8-IP*H60mm		Nipple 1ea 1/4-IP*H60mm	
Mounting strap 1ea W4-1/8"*E1"*H5mm		Hex Nut 2ea 5/32-IP*H3mm	
Part Needed _____		Quantity _____	
Part Needed _____		Quantity _____	
Reason why _____	(missing, scratched, broken glass, bent, bad finish)		
Comments _____			


FIXTURE ASSEMBLY INSTRUCTIONS

Read and review installation instruction sheet before assembling the fixture.


ASSEMBLING THE FIXTURE as Semi flush (Fig. 1)

NOTE: Assemble on a cushioned surface to prevent damage to glass finish.

- Gently spread the arms until evenly spaced if arms are packed closed.
- Place the glass (X) into the Frame ring (Y), and make the top of glass level. Then thread the screw (O) into the arm (N) and frame ring (Y), tighten the fixture arms to the frame with the allen wrench (P).



- Install the light bulbs in accordance with the fixture's specification.
(DO NOT EXCEED MAXIMUM WATTAGE RATING!)



For Customer Service, contact the place of purchase to arrange for replacement parts.

PARTS & ASSEMBLY SHEET

Fixture Name: Hampden 6262-SF DNI

ASSEMBLING THE FIXTURE as Chain hung (Fig.2)

1. Remove the Circular strap from top of Fixture and replace the long mounting screws with two short screws to hold the Deco nuts (E) in place on the fixture Top cap (D).

2. Feed the fixture wires through the Top loop (D0) and pull the wires until taut. Then screw the Top Loop (D0) to the coupling on the top of fixture (D) until tight.

3. By measuring determine correct number of links needed for proper hanging height. Use a pair of pliers to open one link of the Chain (C2) then remove the excess Chain (C2) and discard it.


4. Use one chain connector(E2) to attach one end of the chain to the Top loop (D0) and close the chain connector.

5. Feed the fixture wires through the Chain (every three links) and pull the wires until taut.

6. Slip Canopy loop collar (B2) over the chain, then do the same with the canopy (F2).

7. When ready to complete the installation Use the other chain connector and attach the other end of the chain to the canopy loop (A2) and close the chain connector.

8. Make sure the weight of the chandelier is supported by the chain-not the electrical wire.



NOTE: Assemble on a cushioned surface to prevent damage to glass finish.

9. Gently spread the arms until evenly spaced if arms are packed closed.


10. Place the glass (X) into the Frame ring (Y), and make the top of glass level. Then thread the screw (O) into the arm (N) and frame ring (Y), tighten the fixture arms to the frame with the allen wrench (P).

allen wrench included with fixture



11. Install the light bulbs in accordance with the fixture's specification.

(DO NOT EXCEED MAXIMUM WATTAGE RATING!)



For Customer Service, contact the place of purchase to arrange for replacement parts.

WARNING ! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE as Semi flush (Fig. 1)




1. Carefully remove the new fixture from the carton and the yellow bag that holds all your parts. Check that all parts are included as shown in the illustration and parts list.
2. Shut off power at the circuit breaker and remove the old fixture from ceiling, including the old mounting strap.
3. The Circular Strap (A) contains several pairs of threaded holes, find the pair of holes that match the hole spacing in your fixture Back Plate (D) and thread the two Mounting Screws (C) half way into the Mounting Strap (A) facing down, Secure in place with hex nuts. These will have their threaded ends protrude through the two holes in the fixture canopy (D).
4. Place the Mounting Strap (A) over the junction
5. Attach the Mounting Strap (A) to the Junction Box using the two mounting screws (B). Tighten the screws (B) securely with screw driver.

CONNECTING THE WIRES (Fig. 2)

6. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
 7. Attach the GROUND wire(GREEN or COPPER) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Strap (A) or connect both wires together using the correct size of wire connectors.
- NOTE: Twist the wires together in the same direction you twist the wire connector onto the wires.
8. Tuck these wire connections neatly into the Junction Box.

FINISHING THE INSALLATION (Fig. 3)

9. Place the fixture's canopy over the Mounting strap (A), adjust the canopy (D) until the Mounting Screws (C) protrude out from the canopy (D) and secure by threading the Decorative nuts (E) on until tight.
 10. Install the light bulbs and glass shade as per the fixture assembly sheet.
- YOUR INSTALLATION IS NOW COMPLETE. RETURN POWER TO THE JUNCTION BOX AND TEST THE FIXTURE.



Fixture Name: Hampden 6262-SF DNI

For Chandelier Light Fixture

WARNING! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE (Fig.1)

- Carefully remove the new fixture from the carton and the yellow bag that holds all parts. Check that all parts are included as shown in the illustration and parts list.
- Shut off the power at the circuit breaker and remove old fixture from ceiling, including the old mounting strap.
- Thread Nipple(C) into Canopy Loop (F) until snug.
- Thread other end of the Nipple (C) with Canopy Loop attached into Mounting Strap (D).
- Place Lock Washer (B) over end of Nipple (C) protruding through Mounting Strap (D) and thread Hex Nuts (A) onto Nipple until tight.
- Take this mounting strap assembly and mount to ceiling junction box with junction box Screws (E). Tighten screw securely with screw driver.
- Unscrew the Canopy loop collar(H) from the Canopy loop. Take the canopy and pass over the Canopy loop. approximately one half of the canopy loop exterior threads should be exposed. Adjust until desired height is reached. *the Canopy loop collar should fit snugly on the Canopy loop after the canopy is installed. Remove Canopy and Canopy lock collar.
- Assemble the fixture and have an assistant or secure support hold the weight of the fixture while you complete the wiring connections.
- Thread the fixture wires and ground wire of the assembled fixture through the canopy loop and nipple and into the outlet box.

CONNECTING THE WIRES (Fig 2)

- Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
 - Attach the GROUND wire(GREEN or COPPER) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Bracket (D) or connect both wires together using the correct size of wire connectors.
- NOTE:** Twist the wires together in the same direction you twist the wire connector onto the wires.
- Tuck these wire connections neatly into the Junction Box.
 - Raise Canopy (G) to the ceiling and secure in place by tightening the Canopy loop collar(H) into the Canopy Loop(F)
 - Install the light bulbs and glass shade as per the fixture assembly sheet.

Fig. 1





Fig.1

Fig. 2



**YOUR INSTALLATION IS NOW COMPLETE.
RETURN POWER TO THE JUNCTION BOX AND
TEST THE FIXTURE.**