



Hardware

(Drawn to Scale)



Fan Parts

(Not Drawn to Scale)




PARTS GUIDE

Hunter



Using this Parts Guide, make sure all parts are included in the box. If parts are missing, DO NOT RETURN




THIS ITEM TO THE STORE, call 888-830-1326 for assistance.

THIS PARTS GUIDE IS FOR REFERENCE ONLY. REFER TO THE INSTALLATION MANUAL FOR FULL ASSEMBLY INSTRUCTIONS.

Parts List	Model #	26421	26420	26446	26447	26448
	Asm. Dwg. #	97449-01	97449-02	97449-03	97449-04	97449-05
	Finish	White	Antique Brass	Brushed Nickel	New Bronze	Brushed Nickel
Item Name	Qty					
Hanger Bracket Assembly	1	96759-03	96759-05	96759-09	96759-30	96759-09
Ceiling Plate						
Canopy						
Hanger Ball / Downrod Assembly						
Washer, Installers Choice						
Canopy Screw						
Locking Screw						
Mounting Isolator						
Flat Washer						
Wood Screw						
Setscrew						
Blade Iron Set	1	93724-05	93724-05	93724-05	93724-05	93724-05
Blade Set	1	75885-61	75885-60	75885-62	75885-63	75006-82
Switch Housing Assembly	1	98950-03	98950-05	98950-09	98950-30	98950-09
Hardware Kit	1	97449-00-680	97449-00-681	97449-00-682	97449-00-683	97449-00-684
Blade Grommet						
Blade Assembly Screw						
Screw, Machine, 6-32						
Wire Connector						
Globe/Shade	3	73978-01	73978-02	73978-01	73978-01	73978-01
Balancing Kit	1	07570-01	07570-01	07570-01	07570-01	07570-01
Pull Chain	1	63756-41	63756-41	63756-41	63756-41	63756-41
Pull Chain	1	63756-42	63756-42	63756-42	63756-42	63756-42
Pull Chain Pendant	2	74393-08	74393-08	74393-08	74393-08	74393-08
Thumb Screw	9	92803-04	92803-04	92803-04	92803-04	92803-04
Light bulb / Bulb	3	77646-04	77646-04	77646-04	77646-04	77646-04


Materiales

(dibujados a escala)




Piezas del ventilador

(no dibujadas a escala)



GUÍA DE PIEZAS



Consulte esta Guía de partes para asegurarse de que todas las partes estén incluidas en la caja.

Si falta alguna parte, **NO DEVUELVA ESTE PRODUCTO A LA TIENDA. Solicite ayuda al 888-830-1326. ESTA GUÍA DE PARTES SOLAMENTE ES REFERENCIAL. CONSULTE LAS INSTRUCCIONES COMPLETAS DE ENSAMBLAJE EN EL MANUAL DE INSTALACIÓN**

Lista de piezas	No. del modelo	26421	26420	26446	26447	26448
	No. del dibujo de ensamble	97449-01	97449-02	97449-03	97449-04	97449-05
	Acabado	White	Antique Brass	Brushed Nickel	New Bronze	Brushed Nickel
Nombre del ítem	Cantidad					
Conjunto del soporte de suspensión	1	96759-03	96759-05	96759-09	96759-30	96759-09
Placa de techo						
Campana						
Bola de suspensión / Conjunto de varilla						
Arandela, selección del instalador						
Tornillo, de campana						
Tornillo de fijación						
Aislador de montaje						
Arandela, plana						
Tornillo, de madera						
Tornillo prisionero						
Juego de soporte de paletas	1	93724-05	93724-05	93724-05	93724-05	93724-05
Juego de paletas	1	75885-61	75885-60	75885-62	75885-63	75006-82
Conjunto del interruptor	1	98950-03	98950-05	98950-09	98950-30	98950-09
Kit de materiales	1	97449-00-680	97449-00-681	97449-00-682	97449-00-683	97449-00-684
Arandela de caucho, de paleta						
Tornillo, de conjunto de paleta						
Tornillo, mecánico, 6-32						
Empalme plástico						
Globo / Pantalla	3	73978-01	73978-02	73978-01	73978-01	73978-01
Kit de equilibrado	1	07570-01	07570-01	07570-01	07570-01	07570-01
Tirador de cadena	1	63756-41	63756-41	63756-41	63756-41	63756-41
Tirador de cadena	1	63756-42	63756-42	63756-42	63756-42	63756-42
Pendiente del tirador de cadena	2	74393-08	74393-08	74393-08	74393-08	74393-08
Tornillo, de mariposa	9	92803-04	92803-04	92803-04	92803-04	92803-04
Bombilla	3	77646-04	77646-04	77646-04	77646-04	77646-04