CAUTION:

This lamp is partially assembled in the factory by qualified craftsmen. Some assembly is required before use. Please follow the assembly instructions carefully.

WARNING! – TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR PERSONAL INJURY:

- --Turn off/unplug lamp and allow to cool before replacing bulb.
- --Do not touch bulb when fixture is turned on.
- --Do not look directly at lighted bulb.
- --Keep materials that burn easily away from lighted bulb.

Assembly: (refer to Fig.1)

- 1) Place Base on floor.
- 2) Screw the column onto the base while pulling cord through bottom.
- 3) Screw the arm assembly onto the column while pulling cord through bottom.
- 4) Loosen the thumb screw a bit to adjust the swing arm in vertical direction.
- 5) Use the handle to adjust the swing arm in horizontal direction.

WARNING:


Never exceed maximum wattage indicated as it may cause fire.

Important Safety Instructions:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

CLEANING:

Use only soft cloth to dust and clean fixture. Never use chemicals or abrasive cleaners as it may damage finish.



Item No.:70383

MADE IN CHINA