

## MODEL#74010

### ASSEMBLY INSTRUCTIONS

**\*\*CAUTION: DO NOT PLUG THE LAMP INTO ELECTRICAL OUTLET BEFORE ASSEMBLY IS COMPLETED\*\***

1. CAREFULLY LAY OUT ALL LAMP PARTS FROM THE BOX AND PLACE THEM ON FLAT SURFACE.
2. SCREW LOWER COLUMN ON BASE.
3. SCREW UPPER COLUMN ON LOWER COLUMN
4. ATTACH SOCKET ASSEMBLY TO UPPER COLUMN.
5. INSERT THE HARP INTO CRADLE.
6. PLACE SHADE ON TOP OF THE HARP AND TIGHTEN WITH FINIAL.

*CHEMICAL OR ABRASIVE CLEANERS.*

### IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG ( ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

