

Installing the SECUREMOTETM Status Monitor

1. Remove the Location Marker Cover. With the garage door in the closed position, install the Location Marker on the top of the garage door. Replace the Location Marker Cover.
2. Remove the Location Sensor Cover. Install the Location Sensor on the garage wall within 2" of the Location Marker (c). Replace the Location Sensor Cover.
3. Tack the two white wires to the wall with the supplied wire staples.
4. Operate the door from close to open to close again.
5. The blue light on the SecuRemote™ device will flash for 10 seconds, indicating you have correctly installed the Status Monitor.

