ASSEMBLY AND INSTALLATION INSTRUCTIONS

OM-CHU009


WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

- 1. Attach the nipple(-a) to the mounting strap, then secure it with a washer and hex nut.
- 2. Attach the mounting strap to the ceiling box by using two mounting screws.
- 3. Adjust the arms of the fixture according to the drawing of the package. **Important:**
 - a. The arms of each tier should be positioned with equal distances between them.
 - b. The arms should be fixed securely.
- 4. Hold up the metal ring to the arms and put the set screws through the holes, then secure them with bolt nuts. (See Fig.1)
- 5. Carefully thread wires through the loop. Screw the loop onto the nipple(-b) until secure.
- 6. Choose the length of the chain you need, then weave the fixture wire and the grounding wire through the chain. Then connect one end of the chain with the loop by using the loop lock.
- 7. Secure the top loop onto the nipple(-a).
- 8. Thread the fixture wire and grounding wire through the collar, canopy, top loop, nipple(-a) and mounting strap in order.
- 9. Connect the link on the other end of the chain with the top loop by using the loop lock.
- 10. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
 - ---The smooth wire (marked) from the fixture to the black wire from the power source.
 - ---The ridged wire (unmarked) from the fixture to the white wire from the power source.
 - ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
 - Carefully tuck the wires back into the ceiling box.
- 11. Attach the canopy to the mounting strap by inserting the top loop and secure it with the collar.
- 12. Attach the glass shades to the glass holders and secure them with the socket rings.

Note: All glass shades of each tier should be on the same horizontal level.

- 13. Install bulbs(not included). See relamping label at socket area or packaging for maximum allowed wattage.
- 14. Turn on the power at main fuse or circuit breaker box.



ING

060113