

Part	Townsend Vormax 1 Piece LHTL	Townsend Vormax 1 Piece RHTL	Vormax HET, LHTL	Vormax HET, RHTL
	2922A104.XXX	2922A105.XXX	4385A104.XXX	4385A105.XXX
Tank Cover	735212-400.XXX	735212-400.XXX	735216-400.XXX	735216-400.XXX
Inlet Valve	7381125-400.0070A	7381125-400.0070A	7381125-400.0070A	7381125-400.0070A
Trip Lever	7381735-200.XXX0A	7381800-200.XXX0A	7381740-200.XXX0A	7381799-200.XXX0A
Bolt Cap Kit	7381251-200.XXX0A	7381251-200.XXX0A	7381251-200.XXX0A	7381251-200.XXX0A
Silicone Flapper	7381424-100.0070A	7381424-100.0070A	7381424-100.0070A	7381424-100.0070A
Flapper Assy w/ Teeter Bar	7381657-200.0070A	7381657-200.0070A	7381657-201.0070A (3)	7381657-201.0070A (3)
Complete Flush Valve Assy	7381655-200.0070A (1)	7381655-200.0070A (1)	7381655-201.0070A (2)	7381655-201.0070A (2)
(1) Assembly does not include Mounting Plate 7381724-200. Mounting Plate 7381724-200.0070A sold separately if needed				
(2) Assembly will be 1.28 (HET) by default with instructions how to adjust float to create the 1.0 (UHET) assembly				
(3) Assembly will be 1.28 (HET) by default with instructions how to adjust float to create the 1.0 (UHET) assembly				

Vormax UHET, LHTL	Vormax UHET, RHTL
4385A114.XXX	4385A115.XXX
735216-400.XXX	735216-400.XXX
7381125-400.0070A	7381125-400.0070A
7381740-200.XXX0A	7381799-200.XXX0A
7381251-200.XXX0A	7381251-200.XXX0A
7381424-100.0070A	7381424-100.0070A
7381657-201.0070A (3)	7381657-201.0070A (3)
7381655-201.0070A (2)	7381655-201.0070A (2)