



Required tools




PK.1005 / 02

800.566.1986 | BALDWINHARDWARE.COM


- 1** Install exterior adapter, trim and cylinder
 Installer l'adaptateur extérieur, la garniture et le cylindre
 Instalar adaptador exterior, embellecedor y cilindro




- 3** Extend latch bolt with supplied keys
 Sortir le pêne demi-tour à l'aide des clés fournies
 Extienda el pestillo con las llaves suministradas



- 2** Install interior adapter
 Installer l'adaptateur intérieur
 Instalar adaptador interior



- 4** Install interior turnpiece
 Installer le tourniquet intérieur
 Instalar la pieza giratoria interior



TEMPLATE


Plantilla
 Gabarit

Door thickness
 Épaisseur de la porte
 Grosor de la puerta

edge of door
 borde de la puerta
 bord de la porte

face of door
 frente de la puerta
 face de la porte

FOLD
 DOBLE
 PLIER



2-3/8" (60 mm)

2-3/4" (70 mm)

backset
 distancia al centro
 écartement

