PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS



DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN : VANITY / COIFFEUSE / TOCADOR

WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- · ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
 NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!





- x1 Vanity x1 Coiffeuse
- x1 Tocador





- x4 Leg * x4 Jambes
- x4 Piernas





- x1 Furniture Tipping Restraint *
- x1 Systeme antibasculement
- x1 Control para evitar vulcos



ASSEMBLY INSTRUCTIONS / NO TICE DE MONTAGE / INSTRUCCIONES DE MONTAJE

DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN: VANITY / COIFFEUSE / TOCADOR

WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

• ALWAYS install tipover restraint provided.

- NEVER put a TV on this product.
 NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
 NEVER open more than one drawer at a time.
 Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!





ASSEMBLY INSTRUCTIONS / NO TICE DE MONTAGE / INSTRUCCIONES DE MONTAJE



DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN : VANITY / COIFFEUSE / TOCADOR

WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

• ALWAYS install tipover restraint

- provided.
- NEVER put a TV on this product.
 NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- · NEVER open more than one
- drawer at a time.

 Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!





REPLACEABLE PART / PARTIE REMPLAÇABLE / PARTE REEMPLAZABLE

DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN: VANITY / COIFFEUSE / TOCADOR

WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

• ALWAYS install tipover restraint

- provided.
- NEVER put a TV on this product.
 NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- · NEVER open more than one
- drawer at a time.
 Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



000 000 000 0000



x6 RP344-KNOB - Knob with Screw * Poignée et vis Tirador y Tornillo

x5 COMGLIDE-10-45 - Common Glide 10in - 45mm * Glissière Carril de deslizamiento

x4 RP344134-LEG - Leg * Jambes Piernas





x1 RC-ANTI-TIP - Furniture Tipping Restraint 🖈 Systeme antibasculement Control para evitar vulcos



x1 RP344134-FELT - Removeable Felt * Fieltro



x4 RC-FG-WHITE - White leveler 🛨 Patin réglable Nivelador

Protect Your Wood or Laminate Flooring

*This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floors without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at locad hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.