# 24" Electric Cooktop

500 Series - Black Frameless NEM5466UC





NEM5466UC Black

The 24" electric cooktop, sleek in design, features optimal temperature control and is ideal for kitchens with a smaller footprint.

#### **Features & Benefits**

Precise temperature control for better cooking results.

Ceramic glass surface makes cooking and cleaning especially easy.

Residual heat indicator — warns if cooktop is warm or hot.

Push-to-turn control knobs.

Ideal for kitchens with a small footprint.

General Properties	
Knob material	Plastic
Element Performance	
Power of Front Left heating element	1,850 W
Power of Back Left heating element	2,200 W
Power of Back Right heating element	1,200 W
Power of Front Right heating element	1,800 W
Element Size	
Dimension of Front Left heating element	6"
Dimension of Back Left heating element	8"
Dimension of Back Right heating element	6"
Dimension of Front Right heating element	7"
Technical Details	
Watts	7,100 W
Circuit breaker	30 A
Volts	208-240 V
Frequency	60 Hz
Plug type	No plug
Energy source	Electric

Dimensions & Weight	
Overall appliance dimensions (HxWxD)	4" x 23 1/2" x 20 1/2"
Required cutout size (HxWxD)	4 1/3" x 22" x 19 1/4"
Minimum distance from counter front	2 1/4"
Minimum distance from rear wall	2"
Net weight	20 lbs

#### **Accessories - Optional**



**HEZ390210** 8" AutoChef® pan



HEZ390230 10" AutoChef® pan



**HEZ390220** 9" AutoChef® pan





Accessories: To purchase Bosch accessories, cleaners & parts please visit www.bosch-home.com/us/store or call 1-800-944-2904 (Mon to Fri 5 am to 6 pm PST, Sat 6 am to 3 pm PST).


Notes: All height, width and depth dimensions are shown in inches. BSH reserves the absolute and unrestricted right to change product materials and specifications, at any time, without notice. Consult the product's installation instructions for final dimensional data and other details prior to making cutout.

## 24" Electric Cooktop

500 Series - Black Frameless NEM5466UC



### **Installation Details**



A: Min. distance from the cooktop cut-out to the wall


B: Max. recessed depth


C: Min. distance between the surface of the cooktop and the underside of the exhaust hood

This distance can be smaller, check installation instructions of exhaust hood

**D:** Min. distance from the cooktop cut-out to the side wall

Measurements in inches (mm)





Accessories: To purchase Bosch accessories, cleaners & parts please visit www.bosch-home.com/us/store or call 1-800-944-2904 (Mon to Fri 5 am to 6 pm PST, Sat 6 am to 3 pm PST).

Notes: All height, width and depth dimensions are shown in inches. BSH reserves the absolute and unrestricted right to change product materials and specifications, at any time, without notice. Consult the product's installation instructions for final dimensional data and other details prior to making cutout.