


INSTALLATION AND WIRING DIAGRAM

HIGH-LINE

ADAPTOR I HORIZONTAL / VERTICAL, FOR 4" CABLE WIDTHS

ART. NO.	150 360ch	chrome
	150 360mc	matte chrome



IMPORTANT SAFETY INSTRUCTIONS



1. Read all instructions!
2. Turn off power prior to any work on the systems.
3. Only a qualified electrician should install this system power feed.
4. For all the wire connections, use UL listed Wire Nuts.
5. Only BRUCK fixtures and components may be used with the system.
6. Total wattage of the system must never exceed the wattage supplied by the low voltage transformer. Please check that the total lamp wattage does not exceed 300W per circuit.
7. Secondary connections must be clean and tight to avoid arcing and overheating!
8. Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE FIXTURE

Contents of Delivery:

HIGH-LINE ADAPTOR I - qty. (1)

Step 1.

- To change High-Line Adapter from vertical to horizontal direction, remove cap (A).
- Remove screws (B) with allen wrench provided.
- Pull arms (C) from adapter, rotate arm and align screw holes. Screw (B) arms back onto adapter, place plastic lid (A) back on.
- To connect High-Line Adapter to cable, screw the two allen screws (D) at the ends of the adapter to the cable. Make sure screws have a clean connection to the cable.

