ASSEMBLY INSTRUCTIONS


ITEM NO: BO-2871TR-DB BO-2871TR-BS

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

- 1. SCREW THE SHADE PART (1) TO POLE (2) AND TIGHTEN BY SET SCREWS (3). MAKE SURE THE SWITCH AND LAMPSHADE ARE IN THE SAME DIRECTION.
- 2. SCREW POLE (2) TO POLE (4).
- 3. INSERT POLE (4) TO BASE (5) AND TIGHTEN THEM WITH THE WASHER AND NUT USING A SPANNER (6).
- 4. JOIN DRIVER (8) TO THE FIXTURE (7).

INSERT PLUG INTO AN OUTLET AND ENJOY YOUR LAMP!!

Use 30W Build-in LED bulb (bulb included)



 $\widehat{\mathbf{2}}$

The switch and lampshade

are in the same orientation

*** PRESS THE PUSH DIMMER SWITCH FOR SOME SECONDS TO DIM THE LIGHT.

*** THIS LED LIGHT PROVIDES LOW MAINTENANCE SERVICE WITH NO BULBS TO CHANGE.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.