

CRAFTMADE™

Melody 54991

PLEASE READ AND SAVE FOR FUTURE REFERENCE.

CAUTION

1. Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.
2. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

GENERAL

Remove all parts and hardware from the box and make sure that none are missing by referencing the illustrations provided.

Bulbs Required (not included): 1 -Medium Base 40 Watt Max.

1-LIGHT CHANDELIER

1. OUTLET BOX (NOT INCLUDED)
2. MOUNTING PLATE
3. OUTLET BOX SCREWS and WASHERS
(pre-attached to outlet box)
4. GROUND SCREW
5. WIRE CONNECTORS
6. MOUNTING SCREW
7. SUPPLY GROUND WIRE (not included)
8. FIXTURE GROUND WIRE
9. WHITE SUPPLY WIRE(not included)
10. RIBBED(or WHITE)FIXTURE LEAD WIRE
11. BLACK SUPPLY WIRE (not included)
12. SMOOTH(or BLACK)FIXTURE LEAD WIRE
13. CANOPY
14. RODS
15. COLUMN
16. FIXTURE
17. GLASS

