

Installation

Follow these instructions carefully to ensure proper installation of the dishwasher and to prevent accidents when washing dishes.

What's included

Make sure all the parts are included in the product package. If you have a question about the dishwasher or the parts, contact a local Dacor customer center or your retailer. The actual appearance of the dishwasher may differ, depending on your model and country.

 CAUTION

After unpacking the dishwasher, keep the packaging materials out of children's reach to ensure their safety.



Top brackets (2)



Ø4 X 12 screws (8)



Protective sticker



Sub foot



Ø4 X 16 screws
(12)



Plastic caps (4)



Custom panel fixers-
Top (2)



Custom panel fixers-
Bottom (2)



Kick plate brackets
(2)



Kick plate




Ø4 X 8 screws (2)



Badge

Installation

Installation kit (not provided)



Electrical tape &
Standard duct tape



Hot water line



90°Fitting ($\frac{3}{4}$ ")




Tube fittings



Hose clamp



Air gap



Rubber connector



Teflon tape or
sealing compound

WARNING

Do not use plastic tubing. Plastic tubing can deteriorate over time and cause a leak inside the tube fitting.

NOTE

- For the hot water line, we strongly recommend using $\frac{3}{8}$ " minimum O.D. copper tubing with a compression fitting or a flexible stainless steel braided hot water supply line.
- You also need a 90°Fitting with $\frac{3}{4}$ " N.P.T. external pipe threads on one end and a fitting sized to fit your hot water line (copper tubing/compression fitting or braided hose) on the other.
- For the power cable, we recommend a jacketed grounded 12-2 cable. Note that some local codes may require the cable to have a BX style metal jacket.