

ITEM# 82360


Mission 25"H, 60"W TV Console

Leick
Home
SINCE 1970

Ph: 262-518-1877
www.todaysdesignhouse.com


Note:

A packet with complete set of hardware can be found by pulling the red ribbon that's easily visible upon opening the box.









—1—

Hardware List

Item	Description	Qty
a	 Bolt 1/4"x1-1/8"	6PCS
b	 Allen wrench	1PC
c	 Washer 1/4"x12mm	6PCS
d	 Flat Shelf Supports	12PCS
e	 Door Pull	4PCS
f	 Machine screw for door pull 5/32"x3/4"	8PCS
g	 Rounded Shelf Supports	8PCS






—2—

Parts List

Item	Description	Qty
A	 Cabinet	1PC
B	 Top Panel	1PC
C	 Side Panel	2PCS
D	 Middle Bottom Panel	1PC
E	 Side Bottom Panel	2PCS
F	 Middle Adjustable Shelf	1PC
G	 Side Adjustable Shelf	2PCS

Assembly Instructions

Two person assembly recommended.

<p>Step 1 Pull the face frame to unfold the cabinet.</p> 	<p>Step 2 Open 4 doors, Screw-in eight rounded shelf supports onto vertical panels, then insert the bottom panels.</p> 
<p>Step 3 Insert two side panels.</p> 	<p>Step 4 Put the top panel on and fasten with 6 bolts. DO NOT OVER TIGHTEN.</p> 
<p>Step 5 Install flat shelf supports and insert shelves.</p> 	<p>Step 6 Install door pulls.</p> 