



**Elegant Furniture And Lighting Inc.**

**USER GUIDE – LED LIGHTED MIRROR**




IF IN DOUBT ABOUT FITTING THIS PRODUCT, PLEASE CONSULT A QUALIFIED ELECTRICIAN

## **IMPORTANT**

PLEASE READ THE INSTRUCTIONS BEFORE SET UP AND INSTALLATION

### COMPONENT PARTS AND FITTINGS



**Mirror**



**Screw & Wall plug x 4**  
(Included in pack)



**Wire nut x 3**  
(Included in pack)

#### **Suggested Tools:**



**Screw driver**



**Drill**

## **Safety Warning**

### **Safety:**

- We suggest you spend a short time reading the instruction leaflet.
- Carefully check that you have all the parts before beginning assembly.
- Keep small parts and fittings out of children's reach and keep children well away from construction area, as the unassembled product contains small parts, which could present a choking hazard.
- We suggest you retain these instructions for future reference.
- This appliance can be used by adults ONLY.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.


### **Caution:**

- In order to avoid overheating, do not cover the mirror.
- Switch off the mains supply and remove the appropriate fuse or switch off the appropriate circuit breaker before commencing installation
- Make sure that there is no danger that the cord or extension cord is inadvertently be pulled or cause anyone to trip when in use.

# Assembly/User Instruction


Please read all instructions carefully. Before you proceed to install, make sure that the power supply is turned off and remains off until installation is complete.

Please note that each part has been assigned a number and proceed in a numerical order.





## Applicable models



- MRE13048
- MRE13072
- MRE13648
- MRE13660
- MRE13672
- MRE14260
- MRE14272



## STEP3. Connect to the main supply



STEP4. Hang up the Mirror on the wall



# Installation Dimensions:

MODEL	A (inch)	B (inch)	C (inch)	Hanged Vertically		Hanged Horizontally		LED length/in	Driver
				D (inch)	E (inch)	F (inch)	G (inch)		
MRE11830	18	30	1.93	16.55	23.94	28.55	11.94	61.42	35W
MRE11836	18	36	1.93	16.55	29.94	34.55	11.94	73.62	35W
MRE12030	20	30	1.93	18.55	23.94	28.55	13.94	66.14	28W
MRE12036	20	36	1.93	18.55	29.94	34.55	13.94	78.74	50W
MRE12040	20	40	1.93	18.55	33.94	38.55	13.94	85.83	50W
MRE12430	24	30	1.93	22.55	23.94	28.55	17.94	73.62	35W
MRE12436	24	36	1.93	22.55	29.94	34.55	17.94	85.83	50w
MRE12440	24	40	1.93	22.55	33.94	38.55	17.94	93.70	50W
MRE12730	27	30	1.93	25.55	23.94	28.55	20.94	79.13	50W
MRE12736	27	36	1.93	25.55	29.94	34.55	20.94	91.34	50W
MRE12740	27	40	1.93	25.55	33.94	38.55	20.94	99.21	50W
MRE13030	30	30	1.93	28.55	23.94	28.55	23.94	85.85	50W
MRE13036	30	36	1.93	28.55	29.94	34.55	23.94	99.21	50W
MRE13040	30	40	1.93	28.55	33.94	38.55	23.94	105.91	50W
MRE13048	30	48	1.93	28.55	41.94	46.55	23.94	122.83	75W
MRE13072	30	72	1.93	28.55	65.94	70.55	23.94	169.69	100W
MRE13636	36	36	1.93	34.55	29.94	34.55	29.94	228.35	50W
MRE13640	36	40	1.93	34.55	33.94	38.55	29.94	118.11	75W
MRE13648	36	48	1.93	34.55	41.94	46.55	29.94	131.50	75W
MRE13660	36	60	1.93	34.55	53.94	58.55	29.94	157.48	75W
MRE13672	36	72	1.93	34.55	65.94	70.55	29.94	181.89	100W
MRE14260	42	60	1.93	40.55	53.94	58.55	35.94	169.29	100W
MRE14272	42	72	1.93	40.55	65.94	70.55	35.94	194.09	100W

