

# LIVING DISTRICT

Collection: Cassie



Installation manual for:

LD7027W24SG W24" E5.2" H7.7" L3

## Installation instructions:

1. Black wire from ceiling(junction box) attaches to "L"wire from the fixture.
  - 2.White wire from ceiling(junction box) attaches to "N"wire from the fixture.
  3. "E" wire from the fixture is attaced to the mounting bracket and an additional "E" wire from the mounting bracket must be secured to the junction box.
  - 4.Secure mounting bracket to the junction box.
  - 5.Insert the mounting bracket screw(P2) into the mounting bracket (P1)
  - 6.Use the screw(P9) to lock the lamp body to the mounting bracket (P1) on the ceiling.
  - 7.Locking the glass shade(P3) on the socket(P4) by tool(P11)
  - 8.Install E12 light source.(Bulbs not supplied)
- The end!

## PARTS LIST



Part Number	Part	Picture	Description	Qty
MB7S04	P1		mounting bracket L4. 72"*W4. 53"*H0. 59"	1
	P2		Mounting bracket screw	2
GS7R01	P3		Glass shade Φ3.5"*H5.9"	3
P-LD7027W24SG-1	P4		E12 holder	3
	P5		Cup Φ2. 4"*H0. 59"	3
	P6		Lamp Arm L24"*H0. 79"*W0. 39"	1
	P7		head tube Φ0. 4"*L2. 8"	2
	P8		Backplate L4. 7"*W4. 7"*H0. 8"	1
	P9		Screw	4
	P10		E12 socket ring	3
	P12		UL18#Ground wire, L9. 84"	1
	P13		UL18#, L6"	1
E12 Tool	P11		E12 Tool	1

"L" = Hot wire

"N" = Neutral wire

"E" = Ground wire