

# LIVING DISTRICT


Collection: Bethany

Installation manual for:

LD7023W24C W27.2" E8.5" H12.5" L3

## Installation instructions:

1. Black wire from ceiling(junction box) attaches to "L"wire from the fixture.
  2. White wire from ceiling(junction box) attaches to "N"wire from the fixture.
  3. "E" wire from the fixture is attached to the mounting bracket and an additional "E" wire from the mounting bracket must be secured to the junction box.
  4. Secure mounting bracket to the junction box.
  5. Insert the mounting bracket screw(P2) into the mounting bracket (P1)
  6. Use the screw(P11) to lock the lamp body to the mounting bracket (P1) on the ceiling.
  7. Locking the fabric shade(P3) with the socket ring(P12)
  8. Install E12 light source.(Bulbs not supplied)
- The end!



## PARTS LIST

Part Number	Part	Picture	Description	Qty
MB7R01	P1		mounting bracket Φ4.53"*H0.59"	1
	P2		Mounting bracket screw	2
FS7R01	P3		Fabric shade (Φ6.7"+Φ3.9")*H5.9"	3
P-7023W24C-1	P4		E12 holder	3
	P5		Anti-edge light cup Φ1.57"*H1.57"	3
	P6		Tube (Φ0.49"*H0.98")	3
	P7		Metal parts (Φ1.23"*H0.47")	3
	P8		Crystal Ball (Φ1.97")	3
	P9		head tube Φ0.45"*L4.13"*T0.047"	1
	P10		BackPlated (Φ4.72"*H0.98")	1
	P11		Screw	2
	P12		Lamp Arm L21.5"*W0.98"*H0.85"	1
	P13		E12 Socket Ring	3
	P14		UL18#Ground Wire, L9.84"	1
	P15		UL18#, L6"	1

"L" = Hot wire

"N" = Neutral wire

"E" = Ground wire