




















Collection: Mascher
 Installation manual for:


OD336W11BK W5" H10.5" E6" L1

Installation instructions:

1. Install E26 light source. (Bulbs not supplied)
2. Connect cover (P9) with body (P12) and put rubber ring (P8) and screw caps (P7) to fixable.
3. Black wire from ceiling (junction box) attaches to "L" wire from the fixture
4. White wire from ceiling (junction box) attaches to "N" wire from the fixture
5. "E" wire from the ceiling attaches to "E" wire from the fixture.
6. Secure mounting bracket (P1) to the junction box.
7. Use screw (P15) to fixable lamp with wall mounted



Part Number	Part	Picture	Description	Qty	
MB12W01	P1		Mounting bracket Ø3.94	1	
	P2		Mounting bracket screw M4	2	
	P3		Screw M4	1	
P-OD336W11BK-1	P4		160*120*27MM Back Plate	1	
	P5		18*18*54MM Tube	1	
	P6		24*24*24MM Box	1	
	P7		Screw cap	2	
	P8		Rubber ring	2	
	P9		127*127*17MM Cover	1	
	P10		E26 Lamp Holder	1	
	P11		122*122*H30MM Body edge	1	
	P12		12*10*H181MM Body	4	
	P13		122*122*H22MM Body Bottom	1	
	P14		117*117MM Plate	1	
	P15		Screw M4	2	
	P16		UL18# Ground wire, L9.8"	1	
	P17		UL18#, L12" Black+White"	1	
	GP12L22	P18		L98*H181MM Glass	4



"L" = Hot wire
 "N" = Neutral wire
 "E" = Ground wire