



Installation manual for 1070G24BK

Dimensions : D24" H21" L9

Collection :Harlow

Bulb Type : E12 bulb not included

Lamp Frame Weight:10 LBS

Total Weight :44 LBS



Thank you for choosing our product(s).


Our Company is actively involved in every step of the production.

Our product(s) are designed to be utilized for every application that graces your home or business.

We pride ourselves in providing the most prompt and courtesy service to all of the valued customers.

Please find the enclosed detailed instruction and read carefully for proper installation.

If you have any questions, please contact the retailer Where the purchased was made.



SAFETY

Warning: MAKE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF. BY EITHER REMOVING THE FUSE OR TURNING OFF THE CIRCUIT BREAKER.


CAUTION

- Before assembling the lighting fixture, please read all instructions carefully.
- All frame & Glass Tube components are fragile, please handle with care.
- Required supply circuit : 110 - 125V/60Hz
- Labeled wires are "L" for live wire, "N" for neutral wire, "E" for ground wire.
- Never install fixture on damp ceiling, the room should be dry and well ventilated
- All electrical components must be installed by a licensed electrician and in accordance with the National Electrical Code and the appropriate local electrical codes.

Unpack the Package

Please open the box carefully and check all the items are inside the box. If you have any installation, assembling and missing parts questions. where you purchase from and any other relevant information ready, our customer service team will provide comprehensive and worry free service to our valued customers.

Frame Assembly Diagram







1070G24BK D24" H21" L9

Step 1
Please use the parts list to ensure you are not missing any parts.

PARTS LIST


Part Number	Picture	Description	Qty	Diagram Number
Cord-142-18#-BK		Power Cord 142" SPT-1 Black	1	P1
CP10R47BK		L142"Ground electrode	1	P2
		Crossbar 4" (Canopy part)	1	P3
		Canopy lock (Canopy part)	1	P4
		D4.7" Metal Canopy	1	P5
		Canopy ring (Canopy part)	1	P7
		loop	1	P8
CHAIN04PBK		L59"CHAIN04P Plain Design	1	P6
P-1070G24BK-1		L4.5"metal tube	1	P9
		Metal nut	1	P10
		M4*L24 Screw	3	P11
		D24"Metal ring	1	P12
		D22.6"Metal ring	1	P13
		L10.6"metal tube	6	P14
		metal lamp cap	9	P15
		E12 Socket	9	P16

1070G24BK D24" H21" L9

Part Number	Picture	Description	Qty	Diagram Number
P-1070G24BK-1		L6.7"metal tube	3	P17
		L6.3"metal tube	3	P18
		D16"Metal ring	1	P19
		D14"Metal ring	1	P20
		M5*L22 Screw	6	P21
		Metal Wire Box	1	P22
		Metal cover	1	P23
		Cap nut	1	P24
CR-1070-RC-CL-A		L7.9"glass tube	116	A

Step 2

Canopy installation instructions



"L"=Hot wire
"N"=Neutral wire
"E"=GND


05

Important: This product must be installed in accordance with the local installation codes by a person familiar with construction and operation of this product and the hazards involved.

1. Black wire from ceiling(junction box) attaches to "L" wire from the fixture.
2. White wire from ceiling((junction box) attaches to "N" wire from the fixture.
3. "E" wire from the fixture is attaced to the mounting bracket and an additional "E" wire from the mounting bracket must be secured to the junction box.
4. Secure mounting bracket to the junction box.
5. Insert screws in side of top unit the mounting bracket.

06

Frame Assembly Diagram



Step 3

Frame Assembly Instructions

Installation:

Please read all instructions carefully.

Before you proceed to install, make sure that the power supply is turned off and remains off until installation is complete.

Please note that each part has been assigned a number.

Please proceed in a numerical order.

1. Attach the fixture to the ceiling.

2. Connect the metal tube(2) to the lamp body assembly(3).

Connect the Canopy part(1) to the fixture.

3. Attach the light body to the chain and lock it tightly.

4. Install the metal tube(4) onto the lamp body(3) and tighten the side screws.


5. Attach the metal ring to the lamp body with screws(7).

As the Glass Tube(A) dressing instruction, hang the Glass Tube parts.

The end!

Step 4 Glass Tube Dressing Instructions

1. Hang Glass Tube:A




09

Glass Tube Dressing Diagram



When dressing the chandelier with the Glass Tubes please remember to wear either rubber or cotton gloves. So as to prevent any damage or smudging on the Glass Tubes.



10

Congratulations !

You are now done installing your Elegant Lighting fixture. Sit back and admire each Glass Tube as it will become the statement piece for your room/house.

Thank you.

Cleaning and Maintenance of Chandelier Frame

The finish on our chandelier frames and fixture frames is protected by a durable coating of lacquer. To clean, use a clean soft, dry cloth. Do not use any metal polishes, cleaners, abrasives or any substance which could remove the protective finish. Failure to follow these instructions automatically voids the guarantee.

Cleaning and Maintenance of Glass Tubes

Wet a soft cotton fabric in clean warm water and wipe gently, then polish with a dry soft cotton fabric.

To Order Glass Tube Replacement Parts

Should you require replacement Glass Tubes or pins (the metal connectors attaching the Glass Tubes), contact the store where the product was purchased or contact us . For ease of ordering, you may use the original Glass Tube trimming instructions provided with this product and circle the items you wish to order, indicating the quantity by writing the number needed adjacent to the circle . You will be contacted with prices prior to shipment. All orders must be pre-paid.

Elegant Lighting Warranty

The finish and frame of your new chandelier or fixture are warranted for a period of one (1) year from the date of purchase. Our company will, at its option, repair or replace any frame that has a defect in the materials or workmanship during the warranty period. All Glass Tubes are guaranteed for their original quality during the life of the chandelier. Breakage is not covered by this warranty.

To make a claim under this warranty, contact our customer service department.

A written return authorization form will be sent to you with specific instructions.

Returns and Conditions of Warranty

Returns must be pre-authorized by contacting our customer service department. Returns will only be accepted with a written return merchandise authorization and return shipping charges pre-paid. We reserve the right to inspect all returned merchandise to fully determine the nature of any defect. This guarantee shall not apply to any product that has been changed, altered or otherwise modified, nor shall it apply to any product that has been repaired or altered by anyone other than a pre-authorized facility. We will not be responsible for any breakage or damages incurred during transit, nor for Glass Tube parts or metal frame part that have been subject to misuse, negligence, accident or inappropriate handling. Also, we will not be held responsible for damage incurred during improper installation or wiring by others, nor for damages resulting from a failure to follow the recommended maintenance or installation procedures. This guarantee is issued in lieu of any and all other guaranteed or warranty, whether written or implied and any and all other obligations or liabilities. Further, we neither authorize nor permit any other person or firm to assume for us, any liability in connection with the sale of our products.