

Includes 1/2" & 3/4" 6-32 Machine Screws


All Plates approx. 5/16" Thick

5 1/8" H x 3" W




**Description**

- Toggle 1, Rope Switch Plate (29211)
- Toggle 2, Rope Switch Plate (29212)
- Toggle 3, Rope Switch Plate (29213)
- Toggle 4, Rope Switch Plate (29214)



5 1/8" H x 4 5/8" W



5 1/8" H x 6 1/2" W




5 1/8" H x 8 9/32" W


5 1/8" H x 3" W




- Rocker 1, Rope Switch Plate (29221)
- Rocker 2, Rope Switch Plate (29222)
- Rocker 3, Rope Switch Plate (29223)
- Rocker 4, Rope Switch Plate (29224)



5 1/8" H x 4 5/8" W




5 1/8" H x 6 1/2" W




5 1/8" H x 8 9/32" W

5 1/8" H x 3" W




- Duplex 1, Rope Switch Plate (29231)
- Duplex 2, Rope Switch Plate (29232)

5 1/8" H x 4 5/8" W




5 1/8" H x 4 5/8" W

5 1/8" H x 4 5/8" W




- Toggle 1, Duplex 1 (29241)
- Toggle 2, Duplex 1 (29242)
- Rocker 1, Duplex 1 (29243)

5 1/8" H x 6 1/2" W




5 1/8" H x 6 1/2" W



5 1/8" H x 4 5/8" W


5 1/8" H x 3" W



3 1/4" C-to-C

Rope Blank Plate (29251)

5 1/8" H x 3" W



3/8" Dia.

Rope Cable Plate (29261)