

INSTALLATION INSTRUCTION

Item NO.:E24273-20PC

NOTE: Only the technical personnel can be allow to fix and maintain.

IMPORTANT!

Make sure that power is switch off at the electricity mains supply before commencing work.

FIXING INSTRUCTIONS

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box
3. Determine desired mounting height and adjust support cables and power cord accordingly. It is recommended to cut excess cables but leave additional 18" for final height adjustment. If support cables are cut reinstall safety stops to ends of cable
4. Turn support rods (1) so they point upwards. Slide cable nuts (3) down cable till support rods touch cable cross supports. Tighten allen screws with wrench (4)
5. Raise fixture to outlet box and loop support cable on inside of canopy onto hook attached to mounting bracket. (See Figure 8)
6. Wire fixture to wires in outlet box. Green wire is for Ground. (Figure9)
7. Install canopy to mounting bracket and tighten 2 screws on side.
8. Level fixture but pushing in lower portion of the adjuster and move wire in or out.
9. After fixture is level adjust power cable and gently tighten screw on strain relief on the bottom of the canopy. Note power cord can be artistically positioned so that it weaves back and forth between support cables.
10. Install maximum 60 watt xenon G9 lamps into fixture.

REPLACEMENT BULB

Do not exceed the maximum wattage.

Light bulbs recommended:

E24273-20PC - 4 X MAX. 60W 120V-60HZ Xenon

CLEANING CARE

Clean with a soft dry cloth.

WARNING!

1. The lamp is for indoor use only

2. Xenon lamps burn at high temperatures. Allow 15 minutes after turned off before touching. Keep all combustibles away from xenon lamps.

