




Computer Desk

196861189418
196861189432



ASSEMBLY INSTRUCTIONS

Before You Begin: A Phillips screwdriver is required (Not Included).

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:














CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE




Serious or fatal injuries can occur from furniture tipping over. You must install the Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.


PARTS

1  TOP x1	2  LEFT LEG x1	3  RIGHT LEG x1
4  REAR PANEL x1	5  MIDDLE PANEL x2	6  DRAWER PANEL x3
7  DRAWER LEFT PANEL x3	8  DRAWER RIGHT PANEL x3	9  DRAWER BACK PANEL x3
10  DRAWER BOTTOM PANEL x3	11  BOTTOM PANEL x1	12  REAR BRACE x1
13  FRONT BRACE x1		

HARDWARE


A  MALE CAMLOCK x50	B  FEMALE CAMLOCK x50	C  WOOD DOWEL x10
D  SELF-TAPPING SCREW M5x50mm x20	E  SELF-TAPPING SCREW M7x70mm x4	F  DRAWER PULL x3
G  HANDLE SCREW M4x18mm x3	H  EVA PAD x4	 ALLEN WRENCH x1


1





(A)		7PCS
(C)		6PCS

2





(D)		8PCS
-----	---	------




3






4




5




6





7




(E)  2PCS


8



(B)  6PCS



(E)  2PCS

9




(H)  4PCS

10




(B)  4PCS 

11



(A) 15PCS


12



(B) 15PCS

13



x3



(A)  12PCS

14


x3



(B)  12PCS 


15

x3




16

x3




(D)



12PCS

17



x3

Ⓕ




3PCS

Ⓖ




3PCS

1. Check Before Installing: Ensure the rails are secure and ball bearings are in place.
2. Prepare: Slide the ball bearings to the front of the rails before closing.



3. Align & Insert: Line up the drawer rails with the main slides and insert both sides at once.




4. Fit: Open and close the drawer slowly three times to align and set the ball bearings.

5.To Remove the Drawer:

Fully extend the drawer.


Push the left release latch up and the right one down.

Pull the drawer out while supporting it.




If the drawer does not go in smoothly please take it out and repeat.

20




21




Drawer Adjustment Instructions


1. Fully extend the drawer.



2. Loosen the screw and then screw it into the second hole position.



3. Slowly move the slide rail downward. While moving, observe the height change of the panel to ensure that the left and right sides gradually become consistent.



4. When the left and right heights of the panel are basically the same, tighten the adjusting device to fix the position of the slide rail. Check the stability and height consistency of the panel again to ensure that the adjustment achieves the expected effect.

※ If there is a height difference on the right panel, Please repeat the adjustment operation on the right panel according to the above steps.

Quality and Safety Guidelines

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please use this item on a stable, level surface only. All table legs should contact the flooring surface when in use. Do not use this item if any instability is detected.
- For maintenance instructions and replacement parts, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- This item is intended to be used as a table only. Do not climb, stand or sit on this item. Do not use this item as a TV stand.
- The item is intended to be used indoors.
- For product longevity, product safety and product integrity, protect from wet and humid weather or other wet, humid or moist conditions and store indoors in a dry location. For additional storage and usage instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please visit www.theubiquegroup.com for our product warranty details or email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.
- Please review and retain all assembly instructions, safety and quality guidelines and product warnings for future reference.
- Please do not slide this product when moving it. Please team lift the item while repositioning it.