


# Microwaves

FFCE2238L W/B



## Countertop

### Product Dimensions

Height	13-7/8"
Width	24"
Depth	19-3/8"

### More Easy-To-Use Features

#### Ready-Select® Controls

Easily select options with the touch of a button.

#### Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

#### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

#### Effortless™ Reheat

Reheat almost anything at the touch of a button.

#### Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

#### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

#### Control Lock Option

#### Electronic Clock/Timer

Helps you keep track of cook times.


#### Interior Light

Illuminates the contents of the microwave for increased visibility.

#### Large Glass Turntable

Even large items fit on our large glass turntable.

#### Available in:



## Signature Features

### Sensor One-Touch Options

Microwave automatically adjusts power levels and cooking times to cook a variety of items, effortlessly.

### One-Touch Keep Warm Setting

Keep food warm until everything — and everyone — is ready.


### Melt & Soften

Use the microwave to quickly melt or soften butter or cheeses for your recipes.

### Easy-Set™ Start

Quickly start cooking — one to six minutes — with just one touch.

Features	
Control/ Timing System	Ready-Select®
Exterior Door Finish	Color-Coordinated
Handle Design	Push Button
Microwave Features	
Microwave Capacity (Cu.Ft.)	2.2
Watts (IEC-705 Test Procedure)	1,200
Interior Light	Yes
Interior Color	White
Turntable Diameter	16"
Turntable On/Off	Yes
Control Lock	Yes
Clock	Yes
Touch Pad Buttons	23
Power Levels	10
Accessory Metal Rack	
Microwave Control Options	
Easy-Set™ Start	Yes
Popcorn Button	Yes
Chicken Nugget Button	
Baked Potato Button	Yes
Sensor Reheat Button	Yes
Snack Button	
Beverage	Yes
Melt & Soften Options	4/ 4
Auto Reheat Options	
Snack Menu Options	
Auto Cook Options	
Auto Defrost Options	Yes
Keep Warm	Yes
Add-30-Seconds	Yes
Sensor Cooking Options	7
Vegetable Cook Sensor	Yes
Delay Start	
User Preferences	
Power Ratings	
Frequency (Mhz)	2,450
Watts @ 120 Volts	1,200
Amps @ 120 Volts	13
Specifications	
Oven Interior Height	11-1/2"
Oven Interior Width	17-1/16"
Oven Interior Depth	18-15/16"
Power Supply Connection Location	Rear
Voltage Rating	120V / 60Hz / 15A
Minimum Circuit Required (Amps)	15
Shipping Weight (Approx.)	48 Lbs.



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



Product Dimensions <sup>1</sup>	
A - Height	13-7/8"
B - Width	24"
C - Depth	19-3/8"

<sup>1</sup>A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)