

Hanover Outdoor Furniture



If you have any problems with this product (missing or damaged parts, assembly issues, etc.),

PLEASE DO NOT RETURN TO THE RETAILER/STORE

from where you purchased the product.

Please call our Toll-Free Customer Service Hotline at: **1-800-416-3511**Between 9:00 AM and 5:00 PM Eastern Time, Monday through Friday

Or visit our website at: www.hanover-products.com


To expedite any future warranty claims, please retain the Instruction Sheet, Warranty Card and receipt for future use.

For additional on-line support on assembly, troubleshooting and care & maintenance of your outdoor furniture, please visit our website at: **www.hanover-products.com**.

6/1/2015 (a)



From behind the chaise lounge back frame, insert a bolt with $\emptyset 8.5x1.5$ mm washer through the hole in the lower sling back frame. Add a $\emptyset 15x4$ mm plastic washer before inserting into the fixed nut in side the sling seat frame (see diagram). **Hand tighten 3-4 revolutions only**. Completely tightening at this point could cause the frame or the sling seat to be uneven. Repeat for the opposite side.



2

Using the hex wrench provided, tighten bolts. Tighten each bolt a few revolutions at time, alternating back and forth between the two bolts until they are completely tightened. It is important to alternate between bolts to ensure your frame and sling seat are even. **Do not over tighten**. Over tightening could damage the threads on the bolts or nuts.

* NOTE: PARTS SHOWN ON PARTS LIST ARE NOT TO SCALE

	PARTS LIST	<u>DESCRIPTION</u>	ORDER PART #	QTY
A	F	SLING SEAT FRAME	AL1584	1
В		SLING BACK FRAME	AL1585	1
С		5/16" X 42 MM BOLT	HW0809	2
D		Ø15 X 4 MM PLASTIC WASHER	HW0026	2
Е		Ø8.5 X 1.5 MM WASHER	HW0005	2
F		HEX BOLT DRIVER	HW0006	1
		ADJUSTMENT BAR FACTORY ASSEMBLY	AL1586	
		BUMPER FACTORY ASSEMBLY	HW0078	
		SLING TUBE CAP-1 FACTORY ASSEMBLY	FC0005	
		SLING TUBE CAP-2 FACTORY ASSEMBLY	FC0468	
		FOOT CAP FACTORY ASSEMBLY	FC0030	

ADL17002