



design • illuminate • enjoy

assembly instructions

Family: Valley | Item No. 4700 VK





notches

▼start here

- **1.** Find a clear area in which you can work.
 - 2. Unpack fixture and glass from carton.
 - 3. Carefully review instructions prior to assembly.

*** The construction of this fixture will be accomplished by first mounting the mounting strap to the junction box, making all necessary electrical connections, mounting the fixture to the wall, and then assembling the main body of the fixture.

- 1. Prepare mounting strap (A) by threading the two 1 1/4" long mounting screws (B) into the back of the gull wing bracket see **Drawing 1**.
- Be sure the holes into which the screws are threaded match the spacing of holes (D) in the back plate (E) see Drawings 1 and 2.

2. Attach mounting strap (A) to junction box (J) using two 1" screws (C) provided - see Drawing 2.

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.

Make electrical connections from supply wire to fixture lead wires. Refer to instruction sheet **(I.S. 18)** and follow all instructions to make all necessary wiring connections. Then refer back to this sheet to continue installation of this fixture.

- 1. Slide backplate (E) over screws (B) and secure with ball knobs (F) see Drawing 2.
 - 1. To install glass, remove threaded socket ring (3) from socket (1) see Drawing 3.
 - 2. Place glass (2) over exposed section of socket (1).
 - 3. Slip spacer (3) and thread socket ring (4) onto socket (1) to secure glass (2).

4. Use socket ring tool to tighten socket ring **(4)**. Notches in socket ring fit into notches on socket ring tool. Tighten socket ring until snug. Do not over tighten.

5. Fixture can now be lamped accordingly.

Note: Maximum wattage for 4700 fixture is 100 watts per bulb.