



HOOKER
— FURNITURE —





ASSEMBLY INSTRUCTION



Item: 5323-90002 Ten-Drawer Dresser
5323-90008 Landscape Mirror

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'ty
A		BOLT	Φ 1/4" × 1-1/2"	8pc
B		LOCK WASHER	Φ 1/4*Φ 12*3"	8pc
C		FLAT WASHER	Φ 1/4*Φ 19*2"	8pc
D		Wrench	10mm	1pc



STEP 1

Adjust leveler if needed to level case on uneven floor.