







ASSEMBLY INSTRUCTION

Item#: 3005-85001 Four-Drawer Thin Console-Ebony

**** Please make sure you have all parts indicated below prior to assembly.
This unit is heavy and can best be assembled with the help of two or more people.**




NO	HARDWARE LIST		Q'TY
A		BOLT	6
B		ALLEN WRENCH	1
C		PLASTIC ANCHOR	2
D		HOOK	2



Assembly steps:

1. Place the top upside down on a soft surface.
2. Attach the post (E) to the top (F), secure by turning in a clockwise direction (See diagram 1)
3. Install other posts in the same way as step 2.
4. Put the bottom panel (G) on the posts.
5. Attach the bottom panel (G) to the posts (E) using 6 bolts (A), secure all bolts with allen wrench (B). (See diagram 2)
6. Turn the Console upright.



Assembly Steps:

- 1. Drill two holes into the wall using 1/4" drill bit at the desired place you want to set the Console and insert the Plastic Anchors (C).**
- 2. Screw the Hook (D) into the Plastic Anchor (C). Check and make sure the Plastic Anchor (C) is securely held in the wall.**
- 3. Hang the metal rings onto the Hook (D) and set the Console in place.**

Above hardware is packed in the plastic bag with the instruction sheet.

Cleaning Instruction: Clean finished parts with a mild dishwashing liquid and water solution on a damp cloth. Polish the finish with soft cloth and an industry recognized furniture polish.