





ASSEMBLY INSTRUCTION

Item#: 1595-10458-WH WRITING DESK

* Please make sure you have all parts indicated below prior to assembly.
This unit is heavy and can best be assembled with the help of two or more persons.

NO	HARDWARE LIST		Q'TY
A		Flat Washer	8
B		Lock Washer	8
C		Bolt	8
D		Allen Wrench	1





Diagram 1

Assembly Steps:

1. Place the desk top (E) upside down on a soft surface to prevent it from scratching.
2. Attach legs (F) to top(E) by using flat washers (A), lock washers (B), bolts (C), secure by turning with Allen Wrench (D) in a clockwise direction. (See diagram 1)
3. Turn the desk upright.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution.
Polish the finish with soft cloth and an industry recognized furniture polish.