


LEG ASSEMBLY INSTRUCTIONS FOR #SS707


SOFA/LOVESEAT/CHAIR/OTTOMAN




1. OPEN THE ZIP AND REMOVE WOODEN LEGS FROM BAG ON BOTTOM OF UNIT



2. SCREW IN THE 4 LEGS



3. COMPLETED ASSEMBLY



HOOKER[®]
FURNITURE