



  
**HOOKER**  
— FURNITURE OUTLET: —  
**ASSEMBLY INSTRUCTIONS**

Parts included ::

1. 1 wooden Top
2. 3 supporting legs
3. 1 Allen Key
4. 3 Big Iron Nuts & Washers.



1. Place the wooden top upside down ( on a protective matt ).
2. Attach the wooden legs to the top 1 by 1 as per the picture & tighten the bolts.



4. After attaching all legs make sure all are fixed firmly and not shaking.
5. Overturn the table carefully.



6. The table is ready to use !

Enjoy using your new table.