

OKER® ASSEMBLY INSTRUCTION

ITEM: 628-55013-80 Suzani Three Door Entertainment Console


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
А	Ø	Anti - Tip Kit		1 PC

Tipping Restraint



The adjustable shelves are screwed in place to avoid damage during transit. To adjust the shelf height, remove screws then place shelf pins in the desired level.

Adjust leveler if needed to level credenza on uneven floor.

Note: Anti-tip kit restraint is provided.
Please follow the instructions enclosed with the pack.